

**FAULT DIAGNOSIS: ZF4HP22 Automatic Gearbox**

Before referring to the fault diagnosis chart, ensure that the following static checks are carried out first:

**INITIAL STATIC CHECKS**


|                       |                                                                |
|-----------------------|----------------------------------------------------------------|
| Check start positions | "P" & "N" only                                                 |
| Reverse lights        | "R" only                                                       |
| Gear engagements      | N-D, N-3, N-2, N-1, N-R                                        |
| Full throttle         | Engine switched off, check full travel at engine and at pedal. |
| Oil level             | "N" selected, engine running at normal running temperature.    |
| <b>Pressure test</b>  |                                                                |
| 2000 rev/min          | 150 $\pm$ 5 p.s.i.                                             |
| Idle pressure         | 100 $\pm$ 5 p.s.i. at 665 to 735 rev/min.                      |

**FIT PRESSURE GAUGE**

**Service tools:**

**18G502A** 0-300 PSI (0-22 kg/cm<sup>2</sup>) pressure gauge.  
**18C502** Flexible hose  
**LST502-11** Hose adaptor

1. Drive the vehicle onto a suitable hoist.
2. From beneath the vehicle, remove the plug from the bottom of the gearbox, fit the adaptor **LST502-11** and tighten securely.
3. Fit the hose to the adaptor and tighten securely.
4. Fit the gauge **18G502A** to the other end of the hose and route to the interior of the vehicle, ensuring that the hose is fastened clear of any rotating parts and exhaust pipes.



5. Remove the vehicle from the hoist and carry out road test.

**Remove the pressure gauge**

6. Drive the vehicle onto a suitable hoist and then reverse instructions 1 to 4.

**FAULT DIAGNOSIS ZF4HP22 AUTOMATIC GEARBOX:****TEST 1**

**SYMPTOM**  
INTERMITTENT DRIVE  
AND HIGH PITCHED  
NOISE

|

**FAULT**  
LOW FLUID LEVEL  
OR  
RESTRICTED FILTER

**TEST 2**

**SYMPTOM**  
NO DRIVE IN  
REVERSE

|

SELECT 'D' | SELECT '1'

---

NO DRIVE | DRIVES FORWARD | NO ENGINE BRAKING

| | |

CONTINUE WITH TEST 3 | **FAULT** | **FAULT**

REVERSE GEAR | CLUTCH BRAKE D

INTERLOCK VALVE  
SEIZED

**TEST 3**

**SYMPTOM**  
NO DRIVE FROM REST  
WITH 'D' SELECTED

|

SELECT '1'

|

NO DRIVE | VEHICLE DRIVES

| |

CARRY OUT MAIN LINE PRESSURE CHECK | **FAULT**

NO PRESSURE | NORMAL PRESSURE | NO 2 FREEWHEEL

| |

**FAULT** | **FAULT**

BLOCK FILTER | CLUTCH A

OR |

PUMP FAILURE |

LOW PRESSURE

|


**FAULT**

RESTRICTED FILTER


OR

STICKING PRIMARY  
REGULATOR


TEST 4




TEST 5




TEST 6




TEST 7




TEST 9




TEST 9




TEST 10




TEST 11




TEST 12




## TEST 13




## TEST 14




## TEST 15




## TEST 16




TEST 17




TEST 18



TEST 19



TEST 20



## TEST 21

SYMPTOM

'1' SELECTED ~~1ST~~ GEAR  
NO ENGINE BRAKING

|  
FAULT

CLUTCH BAND 3

---

## TEST 22

SYMPTOM

'2' SELECTED ~~2ND~~ GEAR  
NO ENGINE BRAKING

|  
FAULT

CLUTCH BAND 1

---

## TEST 23

SYMPTOM

VEHICLE DRIVES  
FORWARD IN 'N'

|  
FAULT

CLUTCH 'A' SEIZED

---

The following repair instructions for the ZF automatic gearbox are divided into three parts. Stage one covers repairs that can be made with the gearbox installed in the vehicle, stage two is with the gearbox removed and stage three a major overhaul procedure.

NOTE: Refer to transfer box section for removal of transfer gearbox.

#### Service Tools

- LST108** -Rear oil seal replacer
- LST109** -Selector linkage setting gauge.
- LST111** -Oil pump rotation sleeve and end float gauge.
- LST112** -Kickdown cable remover.
- LST113** -Control unit inlet oil seals remover/replacer.
- LST114** -Selector shaft oil seal replacer.
- TX27** -Torx bit.
- TX30** -Torx bit.
- 18G1501** -Torque converter remove/refit handles.
- LST115** -B clutch assembly puller hooks.

- LST116** -B clutch 'O' ring and snap ring replacer.
- LST117** -Gear train remover and replacer.
- LST118** -Transmission holding fixture.
- LST1016-1** -Adaptor clutch spring compressor.

#### Gearbox Data

Axial end float 0.2 to 0.4 mm (0.008 to 0.016 in).

From torque converter boss to torque converter housing face 50 mm (1.96 in).


Freewheel cage assembly to ring gear; minimum clearance 0.1 mm (0.0039 in).

Output shaft above cylinder F assembly; dimension 10.00 mm (0.354 in).

A cylinder protrusion above gearbox front face not more than 8.5 mm (0.33 in).


In addition to the above service tools, the following items should be manufactured locally to facilitate dismantling and re-assembly of the gearbox.

#### TRANSFER AND AUTOMATIC ADAPTOR PLATE




RR739M


NOTE: The fixture below can either be manufactured or purchased: figure number **LST 118**.



AUTOMATIC GEARBOX HOLDING FIXTURE




RR1520M



RR524M


1. GEARBOX ASSEMBLY
2. INHIBITOR SWITCH ASSEMBLY
3. CONTROL UNIT ASSEMBLY
4. FILTER AND SUMP ASSEMBLY



1. TORQUE CONVERTER HOUSING ASSEMBLY
2. GEARBOX PUMP AND CASING ASSEMBLY
3. GOVERNOR AND ADAPTOR HOUSING ASSEMBLY


RR525M

1. A CLUTCH ASSEMBLY
2. B CLUTCH ASSEMBLY




RRS26M

## 1. C,C<sup>1</sup> AND D CLUTCH ASSEMBLY




1. FREEWHEEL AND FOURTH GEAR ASSEMBLY



11


## 1. E AND F CLUTCH ASSEMBLY



STAGE 1

Inhibitor switch leak elimination


1. Place vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle disconnect the inhibitor lead.
3. Undo and remove the bolt and spring washer.
4. Remove the retaining plate.
5. Using a suitable tool remove the inhibitor switch from the casing.
6. Fit a new inhibitor switch, retaining plate if existing one is damaged, spring washer and bolt.
7. Reconnect the inhibitor leads.



Intermediate plate screw plugs leak elimination.

NOTE: The following procedure is for all four plugs on the plate. Seals that actually leak should be replaced.

1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle, using a suitable wrench remove the two hexagon headed plugs situated in the intermediate plate, catching any oil that may leak from the plate.




3. Remove and discard the sealing rings.
4. Fit new sealing rings and refit the plugs to the specified torque.
5. Using a suitable hexagon shaped tool, remove the two hexagon socket plugs, catching any oil that may leak from the plate.
6. Remove and discard the sealing rings.
7. Fit new sealing rings and refit the plugs to the specified torque.
8. Connect the battery.
9. Top up the gearbox with the correct oil through the filler level tube located within the engine bay. (See Section 09).
10. Ensuring the vehicle is on level ground with the parking brake applied check oil level while engine is running at idle with neutral selected after selecting each gear.

Continued


## Selector shaft leak elimination

1. Place vehicle on a hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle remove the nut and gear-change lever.
3. Using a suitable tool remove the oil seal.
4. Fit the new oil seal using the selector shaft oil seal replacer LST114. For ease of fitment use a light grease or Petroleum Jelly.
5. Refit gear-change lever, ensure that it is located correctly.
6. Fit and tighten nut to the specified torque (see section 06-Torque values).



## Oil pan leak elimination

1. Place vehicle on a suitable hoist or over a pit open the hood and disconnect battery leads.
2. From underneath the vehicle drain the gearbox using a suitable container and remove the oil filler level tube.
3. Remove the six retaining plates and bolts.
4. Remove the sump and discard the gasket.
5. Inspect sump for wear or damage. Replace if necessary.
6. Fit new gasket onto sump.
7. Refit sump using the six retaining plates and screws (two straight and four corner plates) to the specified torque (see section 06-Torque values).




8. Reconnect oil filler level tube, sump plug with a new seal to the specified torque (see section 06-Torque values).
9. Connect the battery leads.
10. Fill the gearbox with the correct oil (See Section 09).
11. Ensuring the vehicle is on level ground with the parking brake applied check oil level while engine is running at idle with neutral selected after selecting each gear.

NOTE: If leak persists and existing oil pan has been refitted, change the oil pan using the same procedure as above.


# **Kickdown cable leak elimination**

1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. Disconnect the **kickdown** cable from the rear of the engine.
3. from underneath the vehicle, using a suitable container drain the gearbox and discard the gearbox sump seal.
4. Remove the oil filler level tube.
5. Remove the six retaining plates and bolts.
6. Remove the sump and discard the gasket.




RR904M

7. Remove the oil screen, undoing the three bolts using a TX27 **Torx** bit.
8. Remove the control unit, undoing the thirteen remaining bolts using a TX27 **Torx** bit.



RR905M


9. Locate the selector cam and remove the nipple holding the **kickdown** cable from its seat.
10. Using the **kickdown** cable remover **LS1102** remove the cable and it's housing from the casing and discard.
11. Fit new throttle cable with new 'O' ring into the casing.



RR906M

Continued

12. Fit the nipple into the cam seat ensuring that the cam has been turned once before fitment. This will spring load the cam.
13. Fit the control unit after cleaning the face with a lint free rag, ensuring the selector shaft locates into the gear shift fork and fit the thirteen bolts loosely by hand.
14. Place the selector linkage setting gauge **LS1109** in position and gently press the control unit in the direction as shown and tighten all thirteen bolts using TX27 Torx bit to the specified torque (see section **06-Torque** values).



RR2189E


15. Remove setting gauge and fit oil screen using **TX27** Torx bit to the specified torque (see section **06-Torque** values).
16. Refit sump with new gasket.
17. Refit the six retaining plates and screws (two straight and four corner plates) to the specified torque (see section **06-Torque** values).
18. Reconnect oil filler tube and sump plug with a new seal to the specified torques (see section **06-Torque** values).
19. Connect the battery leads.
20. Fill the gearbox with the correct oil (see Section 09).
21. Connect the **kickdown** cable to the rear of the engine.

NOTE: The **kickdown** cable must be adjusted while the vehicle is running at idle.

22. Adjust the cable sheath to achieve a crimp gap of 0.25 to 1.25 mm (**.010** to **.050** in).
23. Hold the cable sheath while tightening the locknuts.
24. Ensuring the vehicle is on level ground with the parking brake applied, check oil level while engine is running at idle with neutral selected, after selecting each gear.

# Extension case leak elimination


1. Remove the transfer box as described in Section 37.
2. Using a suitable tool release the four bolts from inside the vehicle holding the transfer gear selector housing and adaptor bracket.
3. From underneath the vehicle using a suitable tool release the nine bolts holding the extension housing.
4. Remove the extension housing and discard the gasket.
5. Place extension housing on the bench and remove the oil seal.
6. Ensure that all the surfaces are clean and the case is free from damage. If damage has been found on the case, replace the case.
7. If the case has to be replaced, fit the two dowels to the case.
8. Fit a new gasket and oil seal using the rear oil seal replacer LS1108.



9. Fit the extension case onto the gearbox ensuring the oil seal is not damaged by the extension shaft.
10. Fit and tighten the nine bolts to the specified torque (see section 06-Torque values).
11. From inside the vehicle refit the four bolts which hold the transfer gear selector housing and adaptor bracket.
12. Secure the four bolts to the specified torque (see section 06-Torque values).
13. Refit the transfer box as described in Section 37.

# Oil Screen


1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle drain the gearbox using a suitable container.
3. Discard the sump plug seal ring.
4. Remove the filler/level tube from the sump.
5. Remove the six retaining plates and bolts.
6. Remove the sump and discard the gasket.
7. Using TX27 Torx bit undo the three screws which hold the oil screen.
8. Remove the oil screen and discard the 'O' rings.
9. Separate the oil screen from the suction tube and discard the 'O' ring and oil screen.
10. Fit two new 'O' rings to the oil screen using a light grease for ease of assembly.
11. Fit the suction tube to the oil screen.
12. Fit the oil screen to the control unit and secure with three bolts using TX27 Torx bit tighten to the specified torque (see section 06-Torque values).



13. Refit the sump using a new gasket.
14. Secure using the six retaining plates and bolts (two straight and four corner plates), tighten to the specified torque (see section 06-Torque values).
15. Reconnect the oil level/filler tube to the specified torque (see section 06-Torque values).
16. Fit sump plug using a new seal to the specified torque (see section 06-Torque values).
17. Connect the battery leads.

Continued


18. Fill the gearbox with the correct oil through the filler/level tube located within the engine bay. (See Section 09).
19. Ensuring the vehicle is on level ground with the parking brake applied, check oil level while engine is running at idle with neutral selected.




RR 922 M

## Control Unit

1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle drain the gearbox using a suitable container.
3. Discard the sump plug seal ring.
4. Remove the oil filler/level tube from the sump.

**RATION**


5. Remove the six retaining plates and bolts.
6. Remove the sump and discard the gasket.
7. Using a TX27 Torx bit undo the three bolts which hold the oil screen.
8. Using a TX27 Torx bit undo the remaining thirteen bolts retaining the control unit.



AR905W

9. Clean the surfaces ensuring no damage has occurred to the mounting face of the case, using a lint-free rag.
10. Fit the new control unit ensuring the selector shaft locates into the gear shift fork and fit the thirteen bolts loosely by hand.


11. Place the selector linkage setting gauge **LST109** in position and gently press the control unit against the tool and tighten all thirteen bolts using TX27 Torx bit to the specified torque (see section **06-Torque** values).



12. Remove the setting gauge and fit the oil screen using TX27 Torx bit to the specified torque (see section **06-Torque** values).
13. Refit the sump using a new gasket.
14. Secure with the six retaining plates and bolts (two straight and four corner plates), tighten to the specified torque (see section **06-Torque** values).
15. Reconnect the oil filler/level tube to the specified torque (see section **06-Torque** values).
16. Fit sump plug using a new seal to the specified torque (see section **06-Torque** values).
17. Connect the battery leads.
18. Fill the gearbox with the correct oil through the filler/level tube located within the engine bay. (See Section **09**).
19. Ensuring the vehicle is on level ground with the parking brake applied, check oil level while engine is running at idle with neutral selected, after selecting each gear.

#### Oil Inlet Sealing Rings

1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle drain the gearbox using a suitable container.




RR913M

3. Discard the sump plug seal ring.
4. Remove the oil filler/level tube from the sump.
5. Remove the six retaining plates and bolts.
6. Remove the sump and discard the gasket.
7. Using a **TX27** Torx bit undo the three bolts which hold the oil screen.
8. Using a TX27 Torx bit undo the remaining thirteen bolts retaining the control unit and remove the control unit.
9. Clean the surfaces ensuring no damage has occurred to the mounting face of the case, using a lint-free rag.
10. Using circlip pliers remove the eight circlips and springs from the gearbox.
11. Using control unit inlet oil seals remover/replacer **LST113** remove the eight oil seals.
12. Clean the orifices and check for damage.

NOTE: If damage has occurred replace the box as described in Stage II.


Continued

13. Using the control unit inlet oil seal remover/replacer LST113 fit the new seals ensuring they are seated fully home.
14. Fit the eight compression springs, the four short ones at the front and the four long ones at the rear of the box.
15. Using circlip pliers fit the eight circlips which retain the compression springs.
16. Fit the control unit ensuring the selector shaft locates into the gear shift fork and fit the thirteen bolts loosely by hand.



RR580M

17. Place the selector linkage setting gauge LST1109 in position and gently press the control unit against the tool and tighten all thirteen bolts using TX27 Torx bit to the specified torque (see section 06-Torque values).




RR2191E

18. Remove the setting gauge and fit the oil screen using TX27 Torx bit to the specified torque (see section 06-Torque values).
19. Refit the oil pan using a new gasket.
20. Secure with the six retaining plates and bolts (two straight and four corner plates), tighten to the specified torque (see section 06-Torque values).
21. Reconnect the oil filler/level tube to the specified torque (see section 06-Torque values).
22. Fit sump plug using a new seal to the specified torque (see section 06-Torque values).
23. Connect the battery leads.
24. Fill the gearbox with the correct oil through the filler/level tube located within the engine bay. (See Section 09).
25. Ensuring the vehicle is on level ground with the parking brake applied, check oil level while engine is running at idle with neutral selected, after selecting each gear.


## Manual Valve Operating Mechanism

1. Place the vehicle on a suitable hoist or over a pit, open the hood and disconnect the battery leads.
2. From underneath the vehicle, using a suitable container drain the gearbox and discard the gearbox sump seal.
3. Remove the oil filler level tube.
4. Remove the six retaining plates and bolts.
5. Remove the sump and discard the gasket.
6. Remove the oil screen, undoing the three bolts using a TX27 Torx bit.
7. Remove the control unit, undoing the thirteen remaining bolts using a TX 27 Torx bit.



RR914M

NOTE: The illustration for the following instructions is located at the top of the following page.




RR582M

8. Locate the selector cam and remove the nipple holding the kick-down cable from its seat.
9. Remove the nut and gear change lever.
10. Using a suitable punch drift out the roll pin from the selector shaft and discard it.
11. Using a suitable tool remove the selector shaft from the box, noting the position of the detent plate.
12. Remove the connecting rod complete with detent plate, accelerator cam, spring and using a suitable tool remove the oil seal and discard.
13. Check all parts for wear or damage and replace as necessary.
14. Using selector shaft oil seal replacer LST 114, fit the oil seal. For ease of fitment use a light grease or Petroleum jelly.
15. Fit connecting rod to detent plate and locate in the box by pushing the selector shaft through from outside of the casing.


NOTE: The detent plate should go back into the box in the same position as noted earlier.

Continued"



RR581M

16. Fit the accelerator cam with the spring
17. Fit the assembly into the box and secure it by pushing the selector shaft through.
18. Align the hole in the selector shaft with the hole in the detent plate and secure with a new roll pin, using a suitable punch.
19. Fit kickdown cable nipple into the cam seat ensuring that the cam has been turned once before fitment. This will spring load the cam.
20. Fit the control unit ensuring the selector shaft locates into the gear shift fork and fit the thirteen bolts loosely by hand.
21. Place the selector linkage setting gauge **LST1109** in position and gently press the control unit against the tool and tighten all thirteen bolts using TX27 Torx bit to the specified torque (see section OC-Torque values).



RR2192E

22. Remove the setting gauge and fit oil screen using TX27 Torx bit to the specified torque (see section 06-Torque values).
23. Refit the oil pan with a new gasket.
24. Refit the six retaining plates and screws (two straight and four corner plates) to the specified torque (see section 06-Torque values).
25. Reconnect the oil filler/level tube, sump plug with new seal to the specified torques (see section 06-Torque values).
26. Connect the battery leads.
27. Fill the gearbox with the correct oil. (See Section 09).
28. Ensuring the vehicle is on level ground with the parking brake applied, check oil level while engine is running at idle with neutral selected, after selecting each gear.


# GOVERNOR HOUSING

1. Remove the transfer box as described in Section 37.
2. Using a suitable tool release the four bolts from inside the vehicle holding the transfer gear selector housing and adaptor bracket.
3. From underneath the vehicle using a suitable tool release the nine bolts holding the extension housing.
4. Remove the extension housing ensuring that the seal is not damaged and discard the gasket.
5. Remove the extension shaft and retaining bolt with 'O' ring.
6. Remove the governor assembly with parking wheel.
7. Remove the two screws holding the governor housing using TX27 Torx bit.
8. Remove the governor housing complete and discard.
9. Inspect the governor hub and parking wheel for damage, if satisfactory, clean.
10. Fit new governor housing complete to governor hub and parking wheel using TX27 Torx bit to the specified torque (see section 06-Torque values).

11. Refit the governor assembly with parking wheel onto the output shaft and push the assembly till fully seated.

**NOTE: To avoid damage to 'O' ring use a light grease or Petroleum Jelly. Ensure the seal rings are snapped together and are seated correctly.**

12. Fit the extension shaft, apply Loctite 270 to the retaining bolt and using a new 'O' ring, tighten the bolt to the specified torque (see section 06-Torque values).
13. Fit new gasket onto rear of gearbox and fit the extension housing, taking care not to damage the seal on assembly.
14. Secure the extension housing using the nine bolts to the specified torque (see section 06-Torque values).
15. From inside the vehicle refit the four bolts which retain the transfer gear selector housing and adaptor bracket.
16. Secure the four bolts to the specified torque (see section 06-Torque values).
17. Refit the transfer box as described in Section 37.



RR500M

## GOVERNOR HUB

1. Remove the transfer box as described in Section 37.
2. Using a suitable tool release the four bolts from inside the vehicle holding the transfer gear selector housing and adaptor bracket.
3. From underneath the vehicle using a suitable tool release the nine bolts holding the extension housing.
4. Remove the extension housing ensuring that the seal is not damaged and discard the gasket.
5. Remove the extension shaft and retaining bolt with 'O' ring and discard 'O' ring.
6. Remove the governor assembly with parking wheel.
7. Remove the two screws holding the governor housing using TX27 Torx bit.
8. Using a TX27 Torx bit unscrew the two bolts and remove the parking wheel and discard governor hub.
9. Remove the security clip and counter-weight.
10. Remove the 'O' ring from off the output shaft and discard.
11. Remove the three seal rings from the 'F' clutch housing shaft.
12. Inspect all parts for damage or wear, replace if necessary.
13. Fit the counter-weight and security clip into the new governor hub.
14. Secure governor housing onto governor hub using TX27 Torx bit to the specified torque (see section OC-Torque values).


15. Fit the parking wheel to the governor hub using TX27 Torx bit to the specified torque (see section 06-Torque values).
16. Fit three new seal rings onto the 'F' clutch housing shaft and fit 'O' ring onto output shaft.

NOTE: For ease of fitment of the 'O' ring use a light grease or Petroleum Jelly.

17. Fit governor assembly and parking wheel onto the output shaft and push the assembly till fully seated.

NOTE: To avoid damage to 'O' ring use a light grease or Petroleum Jelly. Ensure the seal rings are snapped together and are seated correctly.

18. Fit new gasket onto rear of gearbox and fit the extension housing taking care not to damage the seal or assembly.
19. Fit the extension shaft and retaining bolt using a new 'O' ring.
20. Secure the extension housing using the nine bolts to the specified torque (see section 06-Torque values).
21. From inside the vehicle refit the four bolts which retain the transfer gear selector housing and adaptor bracket. Secure the four bolts to the specified torque (see section 06-Torque values). Refit the transfer box as described in Section 37.




RR919M

**PARKING PAWL MECHANISM**

1. Remove the transfer box as described in Section 37.
2. Using a suitable tool, release the four bolts from inside the vehicle holding the transfer gear selector housing and adaptor bracket.
3. From underneath the vehicle, using a suitable tool, release the nine bolts holding the extension housing.


**NOTE:** The illustration for the following replacement is located at the top of the following page.

4. Remove the extension housing ensuring that the seal is not damaged and discard the gasket.
5. Remove the extension shaft and retaining bolt with 'O' ring, discard the 'O' ring.
6. Remove the governor assembly with parking wheel.



RR584M

7. Remove guide plate bolt, using TX27 Torx bit.
8. Remove the plate and guide plate from the gearbox case.
9. Remove the pin, pawl and the spring.



RR920M

**NOTE:** Take care when removing the assembly. Do not damage parts which could weaken spring tension.

10. Inspect all parts for wear or damage and replace if necessary.
11. Fit the pin and the leg spring ensuring that the spring is located correctly.
12. Fit the pawl onto the pin and the spring leg into the hole in the pawl. This creates tension in the spring.
13. Fit the plate and guide plate using TX27 Torx bit to the specified torque (see section 06-Torque values).
14. Refit the governor assembly with parking wheel onto the output shaft and push the assembly till fully seated.

**NOTE:** To avoid damage to 'O' ring use a light grease or Petroleum Jelly. Ensure the seal rings are snapped together and are seated correctly.

15. Fit new gasket onto rear of gearbox and fit the extension housing, taking care not to damage the seal or assembly.
16. Fit the extension shaft and retaining bolt using a new 'O' ring.
17. Secure the extension housing using the nine bolts to the specified torque (see section 06-Torque values).
18. From inside the vehicle refit the four bolts which retain the transfer gear selector housing and adaptor bracket.
19. Secure the four bolts to the specified torque (see Section 06-Torque values).
20. Refit the transfer box as described in Section 37.

## STAGE II

**WARNING:** Where the use of a transmission hoist is necessary, it is **ABSOLUTELY ESSENTIAL** to follow the hoist manufacturers instruction to ensure safe and effective use of the equipment.


## ZF Gearbox-Remove and refit

## Removing


1. Install the vehicle on a hydraulic hoist.
2. Open the hood.
3. Disconnect the **battery** leads.
4. Release the airflow meter to plenum chamber hose.
5. Disconnect the **kickdown** cable from throttle linkages located on the throttle lever bracketry at the rear of the plenum chamber. Remove the transmission dipstick.
6. Remove the fan cowl from the radiator.
7. From inside the vehicle remove the four screws securing the glove box liner to the glove box and lift out the liner.
8. Carefully pry the window lift switch panel away from the front of the glove box. Identify each switch connection for re-assembly, disconnect the plugs and remove the switch panel.
9. Remove the main and transfer gearbox knobs.

**NOTE:** Refer to Automatic Gear Selector-Panel Illumination in Section **86 Electrical**, page 27, for the removal and refit of the main gear selector lever.

10. Carefully pry the centre panel out of the floor mounted console and remove it from the vehicle.




11. Release the two bolts and two screws securing the console assembly to the gearbox tunnel.
12. Release the parking brake and remove the cotter pin, **clevis** pin and washer securing the parking brake cable to the parking brake lever.



13. Carefully maneuver the console assembly away from the radio housing and remove it from the vehicle.
14. Release the large nut retaining the parking brake outer cable to the top of the gearbox tunnel.
15. Remove the nut and feed the cable through the hole in the tunnel to the underside of the vehicle.
16. Raise the vehicle on the hoist and drain the gearbox.


**NOTE:** The illustration for the following removal instructions is located at the top of the following page.

17. Release the nut and clamp securing the speedometer cable to the rear of the transfer box.
18. Withdraw the cable from the speedometer drive pinion.
19. Release the cable from the clips at the side of the gearbox.
20. Release the four nuts and bolts securing the rear drive shaft to the rear output flange and tie the shaft to one side.
21. Remove the four nuts and bolts securing the front drive shaft to the front output flange and tie the shaft to one side.
22. Release the nuts and bolts securing the front down-pipes to the front catalysts.
23. Release the nut at the rear tailpipe bracket, disconnect the catalysts from the downpipes, and tie the rear tail pipe and muffler to one side.



**RR1995E**

24. Disconnect the oil filler tube from the front of the gearbox oil pan.
25. Disconnect the two oil cooler pipes from the rear of the gearbox bellhousing.
26. Remove the bolts securing the cross-member in position, using suitable equipment expand the chassis and withdraw the cross-member.
27. Remove the front cover from the bottom of the torque converter housing. Remove one converter drive bolt. Mark both the flexible drive plate and the torque converter to ensure the unit is reassembled in the original build position. Remove the remaining three bolts.



**RR1994E**

28. Disconnect the inhibitor switch.
29. Disconnect the selector linkage.
30. Attach the transmission jack using the adaptor plate (illustration RR739W).

31. Remove the nuts and bolts holding rear left-hand side, mounting bracket to chassis.
32. Remove the nuts and bolts holding right-hand side mounting bracket to chassis.
33. Lower the jack until the rear brake drum clears the rear passenger footwell.
34. Remove the cotter pin and washers securing the differential lock lever to the connecting rod, and disconnect the lever from the rod.
35. Disconnect the electrical leads from the differential lock switch and neutral warning switch.
36. Remove the breather pipe from the top of the transfer gearbox.
37. Using a suitable floor jack support the rear of the engine.
38. Remove the torque converter housing to engine bolts.
39. Carefully withdraw the gearbox and transfer box from the engine taking care not to damage any seals.

Continued ..

## Refitting

40. Reverse the removal instructions.

Observe the following points:  
Ensure that the torque converter and flexible plate are in their original positions.

41. Refill the gearbox with the correct grade and quantity of oil (see Section 09).


## Kickdown cable adjustment

42. Kickdown cable must be checked and adjusted as follows:

NOTE: The kickdown cable must be adjusted while the vehicle is running at idle.

43. Adjust the outer cable to achieve a crimp gap of 0.25 to 1.25mm (.010 to .050 in) dimension A.


44. Hold the outer cable while tightening the locknuts.



RR2080E

## Gear lever selector cable setting

45. Remove the split pin and washer securing the trunnion to the gear change lever at the gearbox and disconnect the trunnion from the lever.
46. Select neutral gear at the gearbox using the gear change lever.
47. Release the clamp securing the outer selector cable, the clamp is attached to a bracket which is mounted on the side of the gearbox extension housing.
48. Select neutral gear. at the gear shift, within the vehicle.
49. Rotate the trunnion clockwise or counter clockwise, until the trunnion will engage with the gear change lever at the gearbox, fit the trunnion and secure in position using a NEW cotter pin and washer.



RR2080E

50. Tighten the outer cable clamp to 22 - 28Nm (16 - 21ft lb).


51. Reconnect the battery leads.

52. Ensuring the vehicle is on level ground with the parking brake applied, check the oil level while engine is running at idle with neutral selected, after selecting each gear.

There are several places where leaks can occur at the front of the gearbox. The following are remedies for curing any one of these problems.

## Eliminating leaks/replacing Torque Converter.


1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench using the torque converter handles 18G1501, remove the torque converter, taking care not to damage the torque converter/oil pump housing oil seal.
3. Replace with new torque converter using torque converter handles 18G1501, checking that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.
4. Refit the gearbox and transfer box assembly as previously described.




RR092M

### Eliminating Leaks on the Pump Housing


1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench and remove the torque converter using torque converter handles **18G1501**, taking care not to damage the converter/oil pump housing oil seal.




3. Remove the twelve hexagonal bolts (inner ring pattern).



4. Remove bellhousing and pump assembly from gearbox case and discard the gasket.
5. Remove the eight hexagonal bolts on the rear of the pump.
6. Screw in two of the bolts, diagonally opposite each other, tap lightly using a soft headed mallet; this will free the pump assembly from the intermediate plate.




7. Remove the shaft sealing ring and 'O' ring from the pump housing and discard.
8. Using oil seal replacer **LST108** fit the shaft seal ring into the pump housing.
9. Fit the 'O' ring onto the circumference of the pump housing.
10. Align the dowel with its hole in the intermediate plate and press the pump housing home.




11. Secure the pump housing to the intermediate plate using the eight hexagonal bolts and tighten to their specified torque (see section 06-Torque values).
12. Place the bellhousing and intermediate plate assembly on the bench, front face up. Using the oil pump rotation sleeve LST111, check that the pump gears rotate freely.
13. Before replacing the intermediate plate and bellhousing assembly, check that the thrust washer and axle cage are seated on the A clutch housing.
14. Place the gasket and disc washer onto the bellhousing and intermediate plate assembly using a light grease or Petroleum Jelly.
15. fit bellhousing and intermediate plate assembly onto gearcase and secure with the twelve hexagonal bolts tightened to the specified torque (see section 06-Torque values).
16. Place the end float gauge LST111 onto the pump housing and check that the axial play is between 0.2-0.4 mm (0.008 in to 0.016 in). If the end float is excessive or tight, replace existing washer, situated at the rear of the intermediate plate, with a suitable washer to give the required end float as stated above.
17. Refit torque converter into housing using torque converter handles 18G1501, checking that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.
18. Refit the gearbox/transfer box assembly as previously described.


Eliminating leaks between gearbox housing and intermediate plate.

1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench and remove the torque converter using torque converter handles 18G1501, taking care not to damage the converter/oil pump housing-oil seal.



3. Remove the 12 hexagonal bolts tinner ring pattern).
4. Remove the bellhousing intermediate plate assembly from gearbox case and discard the gasket.






RR576M

5. Place new gasket onto intermediate plate using a light grease or Petroleum Jelly.
6. Before replacing the intermediate plate/bellhousing assembly check that the thrust washer and axle cage are seated on the A clutch housing.
7. Fit bellhousing/intermediate plate assembly with disc washer onto gearcase and secure with the twelve hexagonal bolts tightened to the specified torque (see section 06-Torque values).
8. Place the end-float gauge LST111 onto the pump housing and check that the axial play is between 0.2-0.4 mm (0.008 in to 0.016 in). If the end-float is excessive or tight, replace existing washer, situated at the rear of the intermediate plate, with a suitable washer to give the required end-float as stated above.
9. Refit torque converter into housing using torque converter handles 18C1501, checking that the dimension from the converter fixing bolt boss to the converter housing case is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.
10. Refit the gearbox/transfer box assembly as previously described.

Continued


## Replacing Bellhousing

1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench and using the torque converter handles **18C1501** remove the torque converter, taking care not to damage the converter/oil pump housing oil seal.



RR897M

3. Remove the eighteen hexagonal bolts.
4. Remove bellhousing.
5. Fit new bellhousing.
6. Secure bellhousing with the eighteen hexagonal bolts to the specified torque (see section 06-Torque values).




RR899M

7. Refit the torque converter into the housing using torque converter handles **18C1501**, checking that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.
8. Refit the gearbox/transfer assembly as previously described.


## REPLACING PUMP

1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench and remove the torque converter using torque converter handles **18C1501**, taking care not to damage the converter/oil pump housing oil seal.




RR897M

3. Remove the twelve hexagonal bolts (inner ring pattern).




RR577M

4. Remove bellhousing and pump assembly from gearbox case and discard the gasket.
5. Remove the eight hexagonal bolts on the rear of the pump.
6. Screw in two of the bolts, diagonally opposite each other, tap lightly using a soft headed mallet; this will free the pump assembly from the intermediate plate.



RR57BM

7. Fit new pump assembly aligning the dowel with its hole in the intermediate plate and press the pump housing home.
8. Secure the pump housing to the intermediate plate using the eight hexagonal bolts and tighten to their specified torque (see section 06-Torque values).
9. Place the bellhousing and intermediate plate assembly on the bench, front face up. Using the oil pump rotation sleeve **LST111**, check that the pump gears rotate freely.
10. Remove bellhousing and pump assembly from gearbox case and discard the gasket.
11. Place the new gasket and disc washer onto the bellhousing and intermediate plate assembly using a light grease or Petroleum Jelly.
12. Fit bellhousing and intermediate plate assembly onto gearcase and secure with the twelve hexagonal bolts tightened to the specified torque (see section 06-Torque values).



RR891M

Continued


13. Place the end-float gauge **LS111** onto the pump housing and check that the axial play is between 0.2-0.4 mm (0.008 in to 0.016 in). If the end-float is excessive or tight, replace existing washer, situated at the rear of the intermediate plate, with suitable washer to give required end-float as stated above.

NOTE: If damage is apparent to the bolts they should be replaced.


14. Refit the torque converter into the housing using torque converter handles **18C1501**, checking that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved, the converter is properly seated in the housing.
15. Refit the gearbox/transfer box assembly as previously described.

#### Replacing Intermediate Plate

1. Remove the gearbox/transfer box assembly as previously described.
2. Place the gearbox on the bench, and remove the torque converter using torque converter handles **18C1501**, taking care not to damage the torque converter/oil pump housing oil seal.




3. Remove the twelve hexagonal bolts (inner ring pattern).




NOTE: The illustration for the following replacement instructions is located at the top of the following page.

4. Remove bellhousing and pump assembly from gearbox case and discard the gasket.
5. Remove the eight hexagonal bolts on the rear of the pump.
6. Screw in two of the bolts, diagonally opposite each other, tap lightly using a soft headed mallet; this will free the pump assembly from the intermediate plate.



7. Remove the 'O' ring from the pump housing and discard.
8. Place the bellhousing and intermediate plate assembly on the bench, front side up.



9. Remove the six remaining hexagon bolts and remove the bellhousing from the intermediate plate assembly.
10. Remove the four screw plugs and seal rings from the intermediate plate, discard the seal rings.
11. Remove the oil cooler pipe adaptors and fit them into the new intermediate plate.
12. Fit plugs and new seal rings into the new intermediate plate.
13. Fit intermediate plate assembly onto the bellhousing.
14. Secure with six hexagonal bolts (outer ring pattern) and tighten to the specified torque (see section 06-Torque values).
15. Place intermediate plate and bellhousing assembly on bench, front face up.
16. Fit the 'O' ring onto the circumference of the pump housing.
17. Align the dowel with its hole in the intermediate plate and press the pump housing home.
18. Secure the pump housing to the intermediate plate using the eight hexagonal bolts and tighten to the specified torque (see section 06-Torque values).
19. Place the bellhousing and intermediate plate assembly on the bench, front face up. Using the oil pump rotation sleeve **LST 11**, check that the pump gears rotate freely.
20. Before replacing the intermediate plate and bellhousing assembly check that the thrust washer and axle cage are seated on the A clutch housing.
21. Place the gasket and disc washer onto the bellhousing and intermediate plate assembly using a light grease or Petroleum Jelly.
22. Fit bellhousing and intermediate plate assembly onto gearcase and secure with the twelve hexagonal bolts tightened to the specified torque (see section OC-Torque values).
23. Place the end-float gauge **LST 11** onto the pump housing and check that the axial play is between 0.2-0.4 mm (0.008 -0.016 in). If end-float is incorrect, replace existing washer, situated at the rear of the intermediate plate, with suitable washer to give required end-float stated above.
24. Refit the torque converter into the housing using torque converter handles **18Q550,1**, checking that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.
25. Refit the gearbox/transfer box assembly as previously described.

**AUTOMATIC GEARBOX-OVERHAUL**
**Remove Torque Converter**


**NOTE:** Refer to Stage II Section for removal of the gearbox from the vehicle.

1. Place gearbox into the transmission holding fixture **LST118** and tighten.


**NOTE:** Care must be taken not to over-tighten as casing will distort.

2. Using the torque converter handles **18G1501** remove the converter from the bell housing.


**CAUTION:** Ensure no damage occurs to the pump bush and seal ring lip when removing the torque converter. The converter is still full of oil even after the gearbox has been drained, so care should be taken when removing the unit.


**Remove Valve Body**

1. Turn the gearbox upside down in the fixture.
2. Remove the six bolts and retaining plates which hold the oil pan.
3. Remove the oil pan and rubber seal and discard seal.
4. Using Torx bit TX27, unscrew the three Torx headed bolts which hold the oil screen and remove. Separate the oil screen from the suction tube and discard the two 'O' rings and oil screen.




5. Using Torx bit TX27, unscrew the thirteen Torx headed bolts which retain the valve block to the gearbox.




RR531M

6. Using circlip pliers remove the eight circlips.
7. Remove the eight springs (four short springs at the front of the gearbox and four long springs at the rear of the gearbox).



RR501M


8. Remove the eight sealing rubbers using tool LST1113 and discard.
9. Remove the circlip, spring and using the tool LST113 remove the restrictor at the rear of the gearbox.



RR1521M

#### Remove Parking Pawl and Governor

1. Engage 'Park' position.
2. Using a suitable wrench unscrew the coupling shaft bolt and remove the 'O' ring.
3. Remove the coupling shaft.
4. Remove the nine bolts and washers from the extension housing.
5. Remove the extension housing and gasket from the gearbox and discard the gasket.
6. Disengage 'Park' position.
7. Withdraw the parking wheel and governor hub.




RR901M

Ji


Continued

8. Unscrew the bolt which retains the guide plate using Torx bit TX27.
9. Disengage the spring and remove, also the pin and pawl.

NOTE: Take care when removing the assembly. Do not damage parts which could weaken the spring tension.




10. Using Torx bit TX30 remove the ten Torx bolts from the rear of casing.




#### Remove inhibitor Switch

1. Using a suitable wrench remove the bolt and spring washer.
2. Remove the retaining plate.
3. Using a suitable tool remove the inhibitor switch from the casing.
4. Discard switch if damaged.




#### Remove Bell Housing and Intermediate Plate

1. Using a suitable socket wrench remove the twelve bolts (inside diameter bolt pattern) holding the bell housing.




2. Remove the bell housing and intermediate plate assembly complete, and discard the gasket.
3. Remove the thrust washer, axle bearing and disc washer from the input shaft.

**NOTE:** Under normal **working** conditions there is no need to separate the bell housing from the intermediate plate assembly. If damage has occurred to either the bell housing or intermediate plate see the appropriate section.




#### Remove A Clutch Assembly

1. Turn gearbox with front facing upwards.
2. Remove input shaft and A clutch assembly from gearbox.




3. Remove inner carrier A, disc, axial bearing and thrust washer.



#### Remove B Clutch Assembly


1. Using two suitable screwdrivers remove the small snap ring in cylinder B.



2. Using the B clutch assembly puller hooks LST15 remove the B clutch assembly.

**NOTE:** To remove assembly, lift up cylinder B until it stops, push **assembly** back down and lift up again using more weight.


Continued




3. Remove support ring and 'O' ring.

#### Remove C, C' and D Clutch Assembly

1. Using a suitable screwdriver remove centre plate snap ring via a hole in the casing.



2. Using tool LS11717 attached to intermediate shaft remove C, C' and D clutch assembly.



3. Remove disc, axial bearing and thrust washer.

#### Remove 4th Gear Assembly

1. Turn gearbox to the horizontal position.
2. Push assembly out from the rear, guiding it from the front of the casing.


# Transmission Gear Selector Assembly and Kickdown Cable

## Remove and overhaul

1. Remove the **kickdown** cable from the cam.
2. Using **kickdown** cable remover LST112, remove the **kickdown** cable from the casing.
3. Using a punch remove the roll pin from the selector shaft.
4. Using a pair of pliers or grips pull the selector shaft from the casing.
5. Remove the stop washer, connection rod, cam and leg spring.
6. Using a screwdriver pry out the seal ring located in the gearbox casing and discard.

NOTE: At this stage the gearbox is totally stripped.


7. Inspect and clean casing ensuring no damage has occurred.



RR915M


## Assemble

8. Fit new seal ring into gearbox casing using selector shaft oil seal replacer LST114.



RR539M

9. Fit connection rod into the stop washer.
10. Place stop washer with connection rod into the gearbox casing and then feed the selector shaft into the casing.
11. Fit the leg spring onto the cam.
12. Place the assembly into the gearbox casing and push the selector shaft through until the hole in the shaft aligns with the hole in the stop washer.
13. Using a suitable punch, fit roll pin with the open side facing the rear of the gearbox casing.
14. Fit new **kickdown** cable assembly into its seat on the gearbox casing.




RR540M

15. Fit the nipple of the **kickdown** cable into the cam seat ensuring the cam has been turned one revolution to load the spring.

NOTE: After gearbox has been refitted check the **kickdown** cable and gear selector adjustments are correct. (See **kickdown** cable adjustment and gear lever selector cable setting).

#### Fit Inhibitor Switch

1. Fit new inhibitor switch if existing one was damaged.
2. Replace retaining plate and fix with spring washer and bolt, securing tightly.




#### 4th Gear Assembly Overhaul

1. Using soft-jawed vice secure the 4th gear assembly by gripping the output shaft.
2. Remove the sun gear.
3. Remove the planet gear assembly.

NOTE: Removal of snap-ring on assembly is not necessary unless damage has occurred.

4. Remove the disc washer, axial bearing and thrust washer.
5. Remove assembly from the vice and turn upside down onto the bench.
6. Remove cylinder F from cylinder E.
7. Remove cylinder E from the freewheel 3rd.
8. Remove axial disc, cage and two thrust washers.

9. Using pliers and screwdriver remove the snap-ring on carrier E.




10. Turn the assembly around and remove the output shaft from ring gear by pushing the gear downwards.

NOTE: Do not remove the snap-ring on output shaft.

11. Place ring gear on bench, teeth side down.
12. Remove carrier E from the ring gear assembly.
13. Remove the freewheel cage assembly from the ring gear by using an upward turning motion.
14. Remove the snap-ring retaining the freewheel ring (inner) to the hollow gear.
15. Remove the freewheel ring (inner) from the hollow gear.
16. Remove freewheel cage from freewheel ring (outer).

NOTE: Care should be taken when removing the freewheel ring, which due to the rollers and springs becoming loose may fall out.

17. Remove the snap-ring retaining the clutch plates and steel plates in cylinder F.
18. Remove four clutch plates and five steel plates from cylinder F.
19. Using clutch spring compressor LST1016-1, press down on the spring plate and remove the split rings.




RR543M

20. Remove the spring plate.
21. Turn the cylinder upside down, using two small punches placed in the holes (diametrically opposite each other), push down and remove the piston.
22. Remove and discard the two 'O' rings from the piston.

NOTE: The five sealing rings do not need to be removed on the cylinder unless any damage has occurred to them.

23. Remove the snap ring from cylinder E.
24. Remove the four clutch plates and five steel plates from cylinder E.
25. Using clutch spring compressor LST1016-1, press down on the spring plate and remove the split rings.
26. Remove the pressure plate.
27. Remove piston E by using air pressure directed into the oil feed hole.




RR564M

28. Remove and discard the two 'O' rings from the piston.


WARNING: Before using an air line ensure all necessary safety precautions are taken to prevent personal injury, i.e., safety glasses, protective clothing etc.

NOTE: Do not remove the snap-ring at the bottom of the E cylinder, unless damaged.

Continued



R1541M



RR547M

## Assemble

29. Fit three seal rings on the outside hub and two seal rings on inside hub of cylinder F if they have been removed.

NOTE: Ensure each seal ring is snapped together.

30. Fit new 'O' rings onto the F piston.

NOTE: For ease of assembly apply Petroleum Jelly on 'O' rings and stretch the inner 'O' ring to avoid damage on installation.

31. Fit piston F into cylinder F.  
32. Fit spring plate using clutch spring compressor ~~LS1116611~~.  
33. Fit the two halves of the split ring to secure the spring plate in position, then remove the clutch spring compressor.  
34. Install the clutch plates and steel plates into the F cylinder starting with a steel plate then clutch plate finishing up with the end plate which is thicker than the normal steel plates.  
35. Fit the snap-ring into cylinder F to retain the clutch plate assembly.

NOTE: Do not confuse the steel plates of F clutch with that of the E clutch. The differences are thus: F clutch-steel plates are thicker and the end plate has no inner teeth.

36. Fit new snap-ring at bottom of cylinder E if it has been removed.  
37. Fit the two 'O' rings onto the E piston.

NOTE: For ease of assembly apply Petroleum Jelly.


38. Fit E piston into cylinder E.  
39. Fit the pressure plate with 'depression' facing downwards.

40. Fit spring plate using clutch spring compressor ~~LS1116611~~.

41. Fit the two halves of the split ring to secure the spring plate in position then remove the clutch spring compressor.  
42. Install the clutch plates and steel plates, starting with a steel plate then clutch plate, finishing up with the end plate which is thicker than the normal steel plates.  
43. Fit the snap-ring into cylinder E to retain the clutch plate assembly.


NOTE: Do not confuse the steel plates of E clutch with that of the F clutch. The differences are thus: E clutch-steel plates are thinner and the end plate has inner teeth.

44. Fit the freewheel ring (inner) to the hollow gear.  
45. Secure using the snap-ring.  
46. Fit freewheel cage into the freewheel ring (outer), and press home.  
47. Turn the freewheel cage in the freewheel ring (outer) until rim of the cage has been seated.  
48. Fit carrier E to freewheel cage assembly.  
49. Fit freewheel cage assembly to ring gear assembly using a clockwise motion.  
50. A minimum clearance of 0.1 mm (0.0039 in) should be obtained between the freewheel cage assembly and ring gear.



RR543M

51. Inspect the output shaft for damage to the snap-ring, if any, replace snap-ring; also remove 'O' ring and discard, replace with new 'O' ring.
52. Align inner teeth of carrier E with freewheel ring (inner) teeth and then place freewheel 3rd assembly onto the output shaft.
53. Secure snap-ring into position, retaining the freewheel 3rd.
54. Fit the steel thrust washer and then the copper thrust washer onto the freewheel 3rd assembly.




55. Fit cylinder E onto freewheel 3rd assembly using a turning motion, ensuring that the teeth of the end plate line up with the freewheel ring touter).

NOTE: When correctly assembled, copper thrust washer must be touching cylinder E assembly. The cylinder E assembly will turn in a clockwise direction when holding the output shaft. If the cylinder E assembly is turned in a counter clockwise direction the freewheel will lock up.

56. Fit the axial cage and axial disc onto the rear of cylinder E.
57. Using a turning motion, fit cylinder F assembly onto cylinder E assembly.

58. When correctly mounted the raised edge of the output shaft will be 10.00 mm (0.393 in) above the top surface of cylinder F assembly.

NOTE: Disengagement of end plate and freewheel ring (inner) will occur if end play exceeds 3.00 mm (0.118 in).



59. Fit the complete 4th gear assembly into the gearbox, ensuring that the oil feed holes in cylinder F line up with the corresponding holes in the gearbox casing.
60. Secure the 4th gear assembly to the gearbox using ten countersunk screws. Tighten screws to the specified torque using Torx bit TX30 (see section 06-Torque values).


NOTE: If screws are not tightened correctly, clutch pressure will be lost in clutch F.

61. Turn the gearbox so that the front of the case is uppermost.
62. Fit the disc washer, axial cage and thrust washer onto the 4th gear assembly.
63. Fit the seal ring onto the planetary case and snap together if ring has been removed.
64. Fit the planetary set into the hollow gear using a turning motion.
65. Fit the sun gear onto the planetary set.

Continued


## Refit park mechanism

1. Turn gearbox into a horizontal position.
2. Fit leg spring over pin and place into rear of gearbox.
3. Fit **pawl** onto pin, to tension spring fit leg of spring into hole of **pawl**.
4. Fit plate and guide plate and tighten to specified torque using Torx bit TX27 (see section 06-Torque values).



RR548M

5. Turn gearbox so that the front of the case is uppermost.
6. Fit the disc and axial cage.



RR549M


## Brakes C, C' and D with planetary sets-overhaul

1. Remove the centre plate assembly.
2. Remove the two brake **C'** clutches and two steel plates from cylinder C-D.
3. Remove freewheel 2nd complete.
4. Remove the two brake **C'** clutches and three steel plates from cylinder C-D.
5. Remove the cylinder C-D with brake D assembly.
6. Remove the support ring from the planetary sets assembly.
7. Remove the front planetary set with freewheel assembly.
8. Remove the **sunshaft** from the assembly.

**NOTE:** Do not remove the **seal** ring from the **sunshaft** unless damaged.

9. Remove the snap-ring from the hollow gear.
10. Remove the hollow gear from the assembly.
11. Remove the rear planetary set.
12. Remove the thrust washer and axial bearing.
13. Remove the intermediate shaft with the hollow gear complete.
14. Remove the axial bearing and two thrust washers, one from each side of the bearing.
15. Remove the distance ring.

**NOTE:** The snap-ring in the **webshaft** need only be removed if damaged.



RR550M


16. Holding the hollow gear with the rear face uppermost, remove the snap-ring.
17. Disconnect the hollow gear from the intermediate shaft.
18. Remove the external snap-ring from the brake D assembly.
19. Remove the four clutch plates and five steel plates from the assembly.

20. Using clutch spring compressor **LS1004-1** press down on the spring plate to remove the split rings.
21. Turn cylinder C-D upside down and using the clutch spring compressor, remove the snap-ring with pliers.
22. Remove the spring plate.

Continued

23. For ease of removal of both piston C and piston D, use air pressure fed through the oil feed holes.

**WARNING:** Before using an air line ensure all necessary safety precautions are taken to prevent personal injury, i.e., glasses, protective clothing etc.





24. Discard 'O' rings from both piston assemblies.  
 25. Using the clutch spring compressor remove the spring plate, as previously explained, from the centre plate assembly.  
 26. To remove the piston use air pressure as previously described and discard 'O' rings.

### Assemble

27. Secure the **webshaft** into a soft-jawed vice.  
 28. Fit the snap-ring if it has been removed into the lower groove.  
 29. Fit the distance ring into the webshaft.  
 30. Place a disc washer and axial cage into the assembly.  
 31. Assemble together the hollow gear with the intermediate shaft and secure with the snap-ring.  
 32. Place the other disc washer onto the rear of the intermediate shaft using grease.  
 33. Fit the intermediate shaft assembly **into** the **webshaft** ensuring the disc washer mates up to the axial cage.  
 34. Using a turning motion fit the rear planetary set **into** the hollow gear.  
 35. Fit the front hollow gear into the **webshaft** assembly and secure with a snap-ring.  
 36. Insert disc washer and axial cage.  
 37. Place support ring onto the **webshaft** assembly.  
 38. Tap the two fitting pegs down **into** the slots on the side of the cylinder C-D if they have been removed.  
 39. Place the two 'O' rings onto piston D.

**NOTE:** For ease of assembly, apply Petroleum jelly to the 'O' rings.





RR552M

40. Fit the D piston into cylinder C-D ensuring that the correct side is selected, that is, the side with the least number of slots in cylinder C-D.
  41. Fit the spring plate and using the clutch spring compressor **LST1016-1**, fit the snap-ring into the groove.
  42. Place the two 'O' rings onto piston C.
- NOTE: For ease of assembly, apply Petroleum Jelly to the 'O' rings.
43. Fit the C piston into cylinder C-D.
  44. Using the clutch spring compressor **LST1016-1**, fit the spring plate and the two halves of the split rings.
  45. With the clutch D opening uppermost, fit the planetary set with freewheel 1st gear onto the hub of cylinder C-D.

46. Fit the clutch plates and steel plates starting with a steel plate then a clutch plate, finishing up with the thin end plate.
47. Fit the snap-ring on the outside of the C-D cylinder which secures the D clutch assembly.
48. Fit two seal rings onto the sunshaft and snap together if they have been removed.
49. Fit the sunshaft into the planetary set, splines first.
50. Turning the whole assembly around so the C clutch side is uppermost, fit the assembly into the webshaft assembly.
51. Fit freewheel second onto the sunshaft, before fitting align the upper and lower halves.

NOTE: To ensure correct fitment of the freewheel second, the top of the assembly is marked with the word 'OBEN'



52. Fit the C clutch plates and steel plates starting with a steel plate then a clutch plate into the longer slots of C-D cylinder.

Continued

53. Fit end plate which has three groups of three teeth, of which the middle tooth must fit into the short slots in the C-D cylinder.
54. Fit the C' clutch assembly starting with a clutch plate ending with a steel plate.

NOTE: When fitting these plates ensure teeth on the outside do not go into the 'V' shaped area of the C-D cylinder.


If thin steel plates have to be added into the C or C' clutch assembly ensure that these plates are placed on the side nearer to the respective pistons.



55. Fit the two 'O' rings onto the piston C'.

NOTE: For ease of assembly, use Petroleum Jelly.


56. Fit C' piston assembly into centre plate.
57. Using clutch spring compressor LST1016-1, fit spring plate and the two halves of the split rings.
58. Place the centre plate onto the C-D cylinder making sure that the 'W' shape in the plate locates in the 'V' shaped hollow in the C-D cylinder.
59. Remove the C, C' and D clutch assembly from vice and place a greased thrust washer to the rear face of the webshaft.
60. Fit the whole assembly into the transmission case using the gear train remover/replacer LST17177, ensuring that the oil feed holes are aligned with those in the bottom of the casing.
61. Secure the whole assembly with a snap-ring which fits into the groove inside the casing.



## Clutch B Overhaul

NOTE: The illustration for the following overhaul instructions is located at the top of the following page.

1. Place B clutch assembly with open face upwards.
2. Remove the snap-ring from inside the assembly.
3. Remove the four clutch plates and five steel plates.
4. Using clutch spring compressor **LST1 016-1**, depress spring plate and remove snap-ring and retaining washer.
5. Remove the spring plate.
6. For ease of removal of the piston B, use air pressure fed through the oil feed hole, then turn assembly upside down and tap lightly on the working surface.



RR558M

WARNING: Before using an air line ensure all necessary safety precautions are taken to prevent personal injury, i.e., safety glasses, protective clothing etc.

7. Remove and discard the two 'O' rings on piston B.
8. Remove seal ring on bottom of B cylinder if damage has occurred.


## Assemble

9. Fit the two 'O' rings onto piston B.


NOTE: For ease of assembly use a Petroleum Jelly.

10. Install piston B into cylinder B.
11. Place spring plate into cylinder B and using clutch spring compressor **LST1 016-1**, fit retaining washer (lips facing upward) and snap-ring.
12. Fit the clutch and steel plates starting with a steel plate finishing with the steel plate with three sets of three teeth grouped together.
13. Fit snap-ring into the clutch B assembly.
14. Turn upside down and fit seal ring and snap together if removed.
15. Install B clutch assembly into the transmission case, clutch plates facing upwards.
16. Using B clutch 'O' ring and snap-ring replacer **LST116**, fit 'O' ring, support ring and finally the snap-ring.


Continued



RR557M



RR559M




RR560M

#### A Clutch Assembly Overhaul

1. Remove the input shaft by holding the A clutch assembly firmly and pushing the shaft against the working surface. Remove the 'O' ring and discard.
2. Using a suitable press, depress the A-B carrier and remove the snap-ring.
3. Remove carrier A-B.
4. Remove the six clutch plates and seven steel plates, plus two wavy spring plates fitted to later transmissions.

NOTE: If there is evidence of clutch slip or if the plates are worn, replace the clutch unit using the latest type.

5. Remove spring plate.
6. For ease of removal of piston A, use air pressure fed through the oil feed hole.



RR561M

7. Remove and discard both 'O' rings on piston A.

**WARNING:** Before using an air line ensure all necessary safety precautions are taken to prevent personal injury, i.e., safety glasses, protective clothing etc.

Continued "


**Assemble**

8. Fit the two 'O' rings onto piston A.
9. **Place** the piston into cylinder A.
10. Fit the spring plate into the cylinder A with the convex side facing the piston.
11. Placing carrier A-B on the bench, fit the clutch unit. If the latest clutch unit is being fitted, see **RR2669E** for the correct build sequence. Note also that one steel plate is of alternative thickness.
12. Fit carrier A-B with the clutch assembly onto cylinder A.
13. Using a suitable press, depress the A-B carrier and secure with the snap-ring.
14. Fit the two seal rings, if removed, and an 'O' ring onto the input shaft.
15. Fit the input shaft into the cylinder A assembly and press downwards until shaft meets the stop.


16. Fit the thrust washer onto the input shaft seat.

**NOTE: Use Petroleum Jelly to retain washer in place.**

17. Install the inner carrier A onto the intermediate shaft within the gearbox.
18. Place the disc washer and axial cage into the inner carrier A.
19. Fit cylinder A assembly into the gearbox using a right to left twisting motion. This will enable the teeth of the clutch plates to mesh into the A-B carrier and inner carrier.




**AR2669E**



**RR562M**

NOTE: When properly engaged the top of the cylinder A should not protrude more than 8.5 mm (0.33 in) above the gearbox front face.




20. Place the thrust washer and axial cage onto the A cylinder.

#### Pump, Intermediate Plate and Bell Housing

##### Remove and Overhaul

1. Place the bell housing on the bench, open face down.
2. Remove the eight hexagonal bolts on the rear of the pump.
3. Screw in two bolts, diagonally opposite each other, tap lightly using a soft-headed mallet, this will free the pump assembly from the intermediate plate.



RR900M


4. Remove the six remaining bolts situated on the inside of the bell housing.
5. Separate the bell housing from the intermediate plate.

##### Pump Assembly

6. Using a suitable tool remove the shaft sealing ring and 'O' ring from the pump housing and discard.
7. Strip, inspect and clean the pump assembly using a lint-free rag.

NOTE: If damage has occurred to the assembly, replace the whole pump.


8. Replace the pump hollow gear and pump gear into pump housing with the marked side of gears facing upwards.



RR565M


Continued

9. Fit the 'O' ring onto the circumference of the pump housing.
10. Using oil seal replacer LS11088, fit the shaft seal ring into the pump housing.
11. Fit the alignment pin into the pump housing.




NOTE: If damage is found replace the intermediate plate.

15. Fit the oil cooler pipe adaptors.
16. Fit the four screw plugs into their correct locations with new seal rings.



#### Intermediate Assembly

12. Remove the four screw plugs and seal rings from the plate and discard the seal ring.
13. Remove the oil cooler pipe adaptors.
14. inspect and clean the intermediate plate with a lint-free rag.





RR568M

Refit bell housing, intermediate plate and pump assembly


17. Inspect and clean the bell housing.

NOTE: If damage is found replace the bell housing

18. Align the dowel in the pump with its hole in the intermediate plate and press the housing into position.
19. Secure the pump housing to the intermediate plate with the eight hexagonal bolts and tighten to the specified torque (see section 06-Torque values).
20. Using the oil pump rotation sleeve LST111 check that the pump gears rotate freely.
21. Place the gasket and disc washer onto the intermediate plate assembly using a petroleum jelly.
22. Fit the intermediate plate onto the gearbox.
23. Fit the bell housing onto the intermediate plate assembly.
24. Secure with the six short bolts which locate on the outside diameter ring pattern within the bell housing and the twelve long bolts which are located in the inner diameter ring pattern. Tighten all the bolts to the specified torque (see section 06-Torque values).




RR569M



RR571M

Continued



RR5700W

25. Using the end-float gauge **LSM11** check the axial clearance 0.2 to 0.4 mm (0.008 to 0.016 in). If the axial clearance is not achieved, remove the bell housing/intermediate plate assembly complete and replace existing disc washer using a thicker or thinner one depending on the reading first taken. Re-assemble bell housing/intermediate plate and check the axial clearance once again. Repeat this operation until axial clearance has been achieved.

#### Checking Axial Clearance

1. Fit **LSM11** end-float gauge onto the output shaft, making sure the outer shaft engages into the pump.
2. Pressing the output shaft towards the rear of the gearbox and tighten the three screws on the gauge.
3. Measure the clearance and note.
4. Now secure the remaining screw which retains the outer shaft to the inner collar.
5. Pull the whole assembly away from the bell housing, measure the clearance and note.
6. Subtract the first measurement from the second to obtain the axial clearance.

#### Extension Housing and Governor-Overhaul

1. Remove the two bolts using Torx bit TX27 retaining the parking wheel.
2. Remove the clip and counterweight from inside the governor hub.
3. Remove the two bolts from the top of the governor hub which releases the housing and discard.
4. Release the retaining clip and discard.
5. Remove the pin, spring, piston and weight from the governor housing.
6. Clean and inspect all parts for damage.

**NOTE:** Replace any part which may be damaged.

7. Remove the seal ring from the extension housing.
8. Clean and inspect the extension housing for damage.

**NOTE:** If the dowels are damaged replace the dowels only. If extension casing is damaged replace the case and dowels.

9. Inspect and clean extension- shaft and bolt for damage, replace if necessary.


### Assemble

10. Fit the pin, spring and piston to the governor housing.
11. Fit the weight on the top of the governor housing and secure with a new retaining clip.
12. Fit the counterweight into the governor hub and secure with the clip.
13. Fit the parking wheel and secure with two bolts using Torx bit TX27 to the specified torque (see section 06-Torque values).
14. Fit the governor housing assembly to the hub and secure with two bolts using Torx bit TX27 to the specified torque (see section 06-Torque values).
15. Turn gearbox over in holding fixture so that the rear of the box is uppermost.

16. Fit the governor/parking wheel assembly onto the output shaft and press the assembly until fully seated.

NOTE: To avoid damage to the 'O' ring use a Petroleum jelly. Ensure the seal rings are snapped together and are seated correctly.

17. Fit the extension shaft and retaining bolt using a new 'O' ring.
18. Fit a new seal to the extension housing using the rear oil seal replacer L51088.
19. Fit a new gasket onto the rear of the gearbox and fit the extension housing taking care not to damage the seal on assembly.
20. Secure the extension housing using the nine bolts to the specified torque (see section 06-Torque values).




Continued

## Refit Valve Body, Oil Pan and Torque Converter


1. Position the gearbox so that the bottom is uppermost.
2. Insert the eight sealing bushes into the oil feed holes using the control unit inlet oil seal remover/replacer LST113.

**WARNING:** Before using an air line ensure all necessary safety precautions are taken to prevent personal injury, i.e., safety glasses, protective clothing etc.


3. As a test to check the function of the clutch and brake assemblies, insert an air gun into the oil feed holes and exert a pressure of 5 to 6 bar (72.5 to 87 p.s.i.).
4. Fit the four short springs into the oil feed holes at the front of the gearbox and four long springs into the oil feed holes at the rear of the gearbox.
5. Fit the eight circlips to retain the springs and sealing bushes.




6. Fit the restrictor, spring and circlip using LST113 into the hole adjacent to the four rear oil feed holes.




7. Place the control unit ensuring the selector shaft locates into the gear shift fork and fit the thirteen bolts loosely by hand.
8. Place the selector linkage setting gauge LST1009 in position and gently press the control unit in the direction shown and tighten all thirteen bolts using Torx bit TX27 to the specified torque (see section 06 Torque values).



9. Remove the setting gauge and fit the suction hose and 'O' ring to new oil screen.
10. Fit the new oil screen with new 'O' ring and secure with the three bolts using Torx bit TX27 to the specified torque (see section 06-Torque values).
11. Fit the oil pan using a new gasket.
12. Secure the oil pan with the six retaining plates (two straight and four corner plates), tighten to the specified torque (see section 06-Torque values).
13. Fit oil pan plug with a new seal.



RR918M



16. Refit the gearbox to the vehicle.
17. Refill the gearbox with the correct quantity of recommended fluid.
18. Reconnect the battery ground terminal.
19. Ensuring that the parkbrake is applied, select neutral gear in the main gearbox and start the engine. While the vehicle is idling in neutral, select all forward and reverse gears and return the gear selector to neutral. Check the fluid level in the gearbox, if necessary, top up to between the maximum and minimum levels on the dipstick. Recheck the fluid level.

14. Turn the gearbox around until the gearbox is horizontal.
15. Using the torque converter remove/refit handles 1801501, install the torque converter into the gearbox.


NOTE: Check that the dimension from the converter fixing bolt boss to the converter housing face is 50 mm (1.96 in). If this dimension is achieved the converter is properly seated in the housing.




ZF MAIN GEARBOX AND BORG WARNER TRANSFER GEARBOX - ADAPTOR PLATE

To assist in the removal of the transmission assembly from the vehicle it is necessary to locally manufacture an adaptor plate to use in conjunction with a transmission hoist.

NOTE: Four holes (A) to be countersunk on underside to suit hoist.



Continued



**RR2862E**

- A: Centre of the lifting hoist  
x: Drill fixing holes to suit hoist table

Material: Steel plate BS 1449 Grade 4 or 14 (Mild Steel).

ZF MAIN GEARBOX AND BORG WARNER  
TRANSFER GEARBOX

Remove and refit


Preparation • under bonnet

**WARNING:** Where the use of a transmission hoist is necessary, it is **ABSOLUTELY ESSENTIAL** to follow the hoist manufacturer's instructions to ensure safe and effective use of the equipment.

1. Place the vehicle on a hydraulic hoist and chock the road wheels.
2. Disconnect the battery negative terminal.
3. Release and remove the fan blade assembly. Note the assembly has a left hand thread.
4. Release the clamp and remove the air intake hose from the neck of the plenum chamber.
5. Disconnect the ~~lockdown~~ cable from the throttle linkage.
6. Release the two gearbox breather pipes from the clip located on the lifting eye at the rear of the right hand cylinder head.
7. Remove the gearbox dipstick.


**Inside** the vehicle

8. Select low range, unscrew and remove the transfer gearbox knob.
9. **Unclip** the top cover of the main gearbox selector and remove the circlip, withdraw the detent button. Remove the circlip above the selector knob retention nut, remove the nut, serrated washer and withdraw the selector knob.
10. Carefully pry the inset panel out of the floor mounted console, complete with gear selector illumination panel and ashtray. Disconnect the electrical multi - plug to the graphics panel, and remove the inset panel.
11. Release the four screws and remove the glove box liner.
12. Carefully pry the window lift switch panel from the front of the glove box. Push the panel complete with switches back through the panel opening and place on the gearbox tunnel.



RR257AM

- 13 Release the two bolts and two screws securing the glove box/console assembly to the gearbox tunnel.





RR2540M

14. Detach the two relays from the inner side of the glove box.
15. Disconnect the electrical leads to the rear cigar lighter.
16. Disconnect the parkbrake cable from the parkbrake lever. Raise the lever ~~while~~ simultaneously detaching the glove box/console assembly from the lower dash. Remove the assembly from the vehicle.
17. Remove the retaining clip and pull the parkbrake adjustment thumb wheel from the outer sleeve. Push the inner sleeve to the underside of the vehicle.
18. Remove the sound deadening trim from the top of the gearbox tunnel.
19. Remove the screws and detach the retaining plate from around the transfer gearbox lever.

Continued

## Under the vehicle

20. Raise the hydraulic ramp.
21. Remove the main and transfer gearbox oil drain plugs. Where applicable remove the filler plug to assist draining and drain the oil into suitable containers. While the oil is draining continue with the following operations.



22. Disconnect the multi - plugs to the Lambda sensors.
23. Remove the front exhaust down pipes and intermediate pipe complete with centre muffler.


**NOTE:** The above operation will require the assistance of a second mechanic to support the exhaust system while the various fasteners are released.

24. Remove the eight bolts securing the cross member. Note it may be necessary to spread the chassis to enable the cross member to be withdrawn.


25. Release the two clamps at the side of the engine sump that secure the two gearbox oil cooler feed and return pipes.
26. Place a suitable container below the gearbox, disconnect the oil cooler feed and return pipes from the bottom and side of the gearbox. Plug the pipes and openings to prevent ingress of foreign matter.
27. Disconnect the dipstick tube from the front of the gearbox oil pan.
28. Mark each drive shaft flange at the transfer gearbox with an identification line to aid re-assembly. Remove the fasteners and disconnect the propeller shafts at the output flanges. Tie the shafts to one side.
29. Release the nut and disconnect the speedometer cable from the rear output housing, tie the cable to one side.
30. Disconnect the main gearbox selector cable and rod from the left side of the gearbox. Lay the cable aside.
31. Disconnect the main gearbox inhibitor switch multi - plug from the main harness.
32. If fitted disconnect the speed transducer multi - plug from the main harness.

## Remove the transmission assembly

33. Remove the nine front cover plate bolts from the bottom of the gearbox bellhousing. Detach the cover plate to gain access to the four torque converter fixing bolts.



34. Rotate the engine using the crankshaft pulley until two of the access holes in the drive plate/ring gear assembly are visible through the bell housing bottom cover opening.
35. Remove the two bolts that are visible through the access holes, which secure the drive plate to the torque converter. Mark one of the access holes and a bolt hole in the converter with an identification line to aid re-assembly and to maintain original build setting.
36. Rotate the crankshaft 180° until the remaining access holes are visible. Remove the remaining two bolts.



RR284E4E

44. Remove the bellhousing bolts noting that one of the bolts also secures the gearbox dipstick tube.
45. Withdraw the transmission assembly from the engine, ensuring that the torque converter is removed with the gearbox and does not stay on engine.

#### Refitting

46. Refitting the gearbox is a reversal of the removal procedure noting the following points.
47. The flexible drive plate to torque converter bolts are to be coated with Loctite 270 prior to assembly.
48. Tighten all fasteners to the specified torque values.
49. New gaskets are to be fitted to the exhaust flanges, all joints other than those fitted with doughnuts, to be coated with exhaust sealer. Check the system, if any leaks are evident reseal as necessary.

37. Position a suitable transmission floor jack on the rear output housing or brake drum to support the weight of the transmission assembly.
38. Remove the bolts and withdraw the transfer gearbox mountings.
39. Fit the previously manufactured fixture on a transmission hoist, raise the hoist and position the fixture and hoist under the transfer gearbox mounting points.
40. Using the original gearbox mounting bolts secure the fixture to the gearbox.
41. Remove the transmission floor jack from the rear of the transfer gearbox.
42. Carefully lower the transmission until the top of the transfer gearbox clears the rear passenger footwell.
43. Position the transmission floor jack under the engine to support the weight while the bellhousing bolts are removed.

11

11

11

11