

Air Intake System - Air Filter, Turbocharger - 09



Job No.

Function of turbocharger	09 – 050
Testing turbocharger boost pressure	09 – 100
Removal and installation of turbocharger	09 – 150
Function of engine overload protection - Turbodiesel	09 – 200
Testing engine overload protection - Turbodiesel	09 – 250
Removal and installation of air cleaner	09 – 400
Removal and installation of air cleaner - Turbodiesel	09 – 400

09-050 **Function of turbocharger**

Turbocharger survey

Engine	Designation	Boost pressure at full load, 4000 rpm, gear lever position 3
602.96	Garrett TB 025 1990 or T 025 KKK K14 ²⁾	0.85-0.95 bar (13.75 - 14.25 psi)
603.96	Garrett TB 03 ¹⁾ ³⁾ or T 03 ¹⁾ ³⁾ KKK K24 ¹⁾ ³⁾	0.85-0.95 bar (13.75 - 14.25 psi)


¹⁾ Optional

²⁾ Production breakpoint at a later point in time
KKK = Kuhnle, Kopp und Kausch.

³⁾ For California with air recirculation valve.


Engine 602.961, Garrett TB 025

- a Boost pressure control
- h Turbine housing valve
- A Fresh air inlet
- B Compressed air
- C Bypass passage
- D Exhaust inlet
- E Exhaust outlet
- H Oil feed
- J Oil discharge




Engine 603.96, Garrett TB 03

- a Boost pressure control valve
- c Compressor housing
- h Turbine housing




Garrett TB 03 with air recirculation valve

- a Boost pressure control valve
- b Air recirculation valve
- c Compressor housing



KKK-K24 with air recirculation valve

- a Boost pressure control valve
- b Air recirculation valve
- c Compressor housing
- h Turbine housing




General

The exhaust gas turbocharger (EGT) is a flow machine. The energy of the engine exhaust gas is used for driving a turbine, which in turn drives a compressor through a shaft. The EGT is installed between the exhaust manifold and the exhaust pipe. It is connected to the engine oil circuit for lubrication and cooling.

A boost pressure control valve, fitted to the turbine housing or separately, ensures that a boost pressure of 0.95 bar is not exceeded. If a problem develops in the boost pressure control valve, engine failure is prevented by means of an engine overload protection system.

The exhaust gases of the engine are passed through the exhaust manifold into the turbine housing (h) and flow onto the turbine wheel (i). The flow energy of the exhaust gases starts the turbine wheel (i) rotating. This causes the compressor wheel (d) which is connected


through the shaft (n) to the turbine wheel (i) to be driven at the same speed. The maximum rotation speed is approx. 135,000 rpm. The fresh air drawn in by the compressor wheel (d) is compressed and sent to the engine.



P07-0473-57A

Functional diagram turbocharger KKK K24 (Engine 603.96)

a	Boost pressure control valve	m	Charge housing
c	Compressor housing	n	Shaft
d	Compressor wheel	A	Fresh air inlet
e	Control line	B	Compressed air (to engine)
f	Axial bearing	C	Bypass passage/boost pressure control valve
g	Bearing bushing	D	Exhaust inlet
h	Turbine housing	E	Exhaust outlet
i	Turbine wheel	H	Oil feed
J	Spring	J	Oil discharge
k	Diaphragm	K	Control pressure
l	Valve		



P09-0026-59

Function diagram


1	Injection pump	a	Boost pressure control valve
103	ALDA unit	d	Compressor wheel
110	Exhaust manifold	e	Control line
137	Turbocharger	f	Air admission
138	Charge air pipe	i	Turbine wheel
S66	Pressure switch, engine overload protection	A	Compressor inlet (fresh air)
Y30	Switch-over valve, engine overload protection	B	Compressor outlet (compressed air)
		C	Exhaust gases to turbine wheel
		D	Exhaust outlet

Air Recirculation Valve

(refer also to EDS Operation No. 07.1-010)
 In order to create more favorable combustion conditions for the trap oxidizer, the air recirculation valve is continuously opened or closed in accordance with the performance

characteristic map.

After the closing operation, a residual vacuum of approx. 30 mbar is retained at the air circulation valve.



P07-0472-57


Function diagram turbocharger KKK with air recirculation valve California

Model year 1986187


a	Control valve, exhaust gas control flap	A	Compressor inlet (fresh air)
b	Air recirculation valve	B	Compressor outlet (compressor air)
c	Compressor housing	C	Bypass passage, boost pressure control valve
d	Compressor wheel	D	Exhaust gas to turbine wheel
e	Connector hose	E	Exhaust gas outlet
	Axial bearing	F	Vacuum connection to vacuum transducer
g	Bearing bush	G	Recirculated air
h	Turbine housing	H	Lubrication oil inlet
	Turbine wheel	J	Lubrication oil outlet
	Compressor spring	K	Boost pressure (control valve exhaust gas control flap)
k	Diaphragm		
	Boost pressure control valve		
m	Intermediate housing		

Boost pressure Control Valve (KKK)

To prevent the boost pressure from rising above a certain level, a boost pressure control valve (a) is attached to the turbine housing (h). The boost pressure is taken from the compressor housing and passed through the connecting hose (14) to the boost pressure control valve. When maximum boost pressure is reached, the boost pressure control valve begins to open and allows the exhaust gas to flow along the bypass passage (c). Part of the exhaust gas flows directly into the exhaust system, resulting in a constant boost pressure level.



- 14 Connecting hose
- a Boost pressure control valve
- e Control line
- h Turbine housing
- j Spring
- k Diaphragm
- l Valve
- C Bypass passage
- E Exhaust gas outlet



Boost pressure diagram • full load

Idle and Lower Part Load


No boost pressure occurs during idling and in the lower part load range; therefore, the engine operates as a naturally aspirated engine.

Upper Part Load and Full Load

As the engine load and speed increase, e.g. with an increase in the exhaust gas flow, the turbine wheel (i) is accelerated producing a boost pressure up to a certain value via the compressor wheel (d). The compressed charge air is passed through the charge air pipe to the individual cylinders. The boost pressure allows an increased quantity of fuel to flow through the ALDA unit at the injection pump.

Although boost pressure exists in the deceleration mode, fuel injection is stopped as a result of the control rod position (deceleration fuel cutoff).

09-1 00 Testing turbocharger boost pressure



P09-0030-59

Tester (001)	connect, disconnect.
Pulse generator (021)	connect, disconnect.
Tester (020) with Y distributor	connect to measuring point "A" and test boost pressure.
Tester (020) with Y distributor	connect to measuring point "B" and test boost pressure.

Tester (020) with Y distributor

connect to measuring point "C" and test boost pressure.

Specification: 0.85-0.95 bar gauge pressure at 4000 rpm full load in drive position "3".

Note

This test can be conducted on the dynamometer or on the road.

If the specified boost pressure is not reached, perform the following checks:

- Connecting line from boost pressure control valve to compressor housing.
- Switchover valve of engine overload protection (09-250).
- White vacuum line and rubber connections.
- If all components are in working order, replace turbocharger.

Test data

Boost pressure at full load in drive position "3" at n = 4000 rpm

0.85-0.95 bar gauge pressure

Special tool




Commercial tester

Digital tester (or tachometer installed in car)

- e.g. Bosch, MOT 002.01
- Sun, DIT 9000
- Sun, FMT-101 9/Master 3,
- Sun, MCM-2110,
- All-Test 361 O-MB

09-150 Removal and Installation of turbocharger



P14-0080-57

Vehicle	drive onto the platform or inspection pit.
Bottom section of noise encapsulation	detach, attach.
Air cleaner	remove, install (09-400).
Hose clip (144)	loosen and detach, attach intake hose (167).
Partition wall (A) between trap oxidizer and air cleaner	remove, install (9 bolts) of which 6 are accessible from above, 3 accessible from below (Figure 4).
Vacuum lines red/violet/brown on EGR valve (60) and red/violet/blue on air recirculation valve	detach, attach.
Clip (119) on corrugated pipe (61)	loosen, tighten. Tightening torque 45 Nm.

Corrugated pipe (61)	remove, install.
Exhaust gas recirculation valve (60)	remove, install. Tightening torque 25 Nm.
Trap oxidizer (139) on exhaust manifold	unbolt, bolt on. Tightening torque 45 Nm.
Supporting bracket	unbolt, bolt on and remove at the same time with trap oxidizer.
Charge air connecting line (138 a)	remove, install. Replace gasket (138 d).
Engine breather	detach, attach.
Mixing pipe (135) with exhaust gas recirculation valve (60)	remove, install.
Oil feed line (141) of turbocharger (137)	unbolt, bolt on. Replace seal.
Mounting bracket (134)	unscrew, screw on.
Nuts (134 a) (from top and bottom)	loosen, unscrew.
Mounting bracket (177)	remove, install.
Turbocharger (137)	remove, install.

Note

The specified tightening torques are reference values.


Removal, installation

Note

For the conversion, the car must be driven onto an inspection pit or platform.


- 1 Completely remove noise encapsulation from below.
- 2 Remove air cleaner entirely.
- 3 Loosen hose clip (144) from air flow sensor and detach intake hose (167).

4 Remove partition wall "A" (9 bolts), of which 6 (WAF10) are accessible from above, 2 (WAF8) and 1(WAF10) accessible from below.




5 Detach vacuum lines red/violet/brown on EGR valve and red/violet/blue on air recirculation valve.

6 Loosen clips "B" on corrugated pipe, and remove corrugated pipe.




7 Unbolt trap oxidizer from exhaust manifold, remove trap oxidizer and supporting bracket at the same time.

8 Remove charge air connecting line (138 a).



9 Detach engine breather hose.


10 Detach mixing pipe (135) with exhaust gas recirculation valve from cylinder head.



11 Unbolt oil feed line (141) from turbocharger (replace seal).

12 Loosen both mounting brackets (134) on the exhaust manifold and turbocharger.

13 Loosen bolts of exhaust pipe - accessible from above (arrows).



14 Loosen bottom bolt of exhaust flange.

15 Unbolt mounting (177) from alternator flange to turbine housing on both components.

16 Remove turbocharger.

17 Install corrugated pipe with flange onto new turbocharger.

18 Clean sealing surfaces mechanically.

20 Install new trap oxidizer, insert supporting bracket at the same time and install. Tightening torque 45 Nm.

21 Install EGR valve together with corrugated pipe.

22 Install partition panel.

23 Connect vacuum line red/violet/brown to EGR valve and vacuum line red/violet/blue to air recirculation valve.


24 Connect intake hose to air flow sensor and tighten hose clip.

25 Install air cleaner complete.

26 Completely reinstall bottom section of noise encapsulation .

09-200 Function of engine overload protection - Turbodiesel



A pressure switch is installed in the charge air pipe as an overload protection for the mechanical parts of the engine. In the event that the boost pressure rises above 1.1 ± 0.15 bar gauge pressure, air is admitted to the ALDA unit through the switchover valve and the fuel quantity is limited to that of a naturally aspirated engine.



- A Naturally aspirated engine quantity (P = 1050 mbar)
 B Full load quantity with turbocharging


Location of Components

- 1 Injection pump
- 2 Governor
- 3 Fuel pump
- 6 Stop unit
- 65 Vacuum control valve
- 103 ALDA unit
- Y22 Actuator



- Y30 Switch-over valve,
 engine overload protection


S66 Switch, engine overload protection



Pressure, vacuum diagrams (refer to 07.1-500).

Wiring diagrams (refer to 07.1-400).

09-250 Testing engine overload protection - Turbodiesel



1	Injection pump	a	Boost pressure control valve
103	ALDA unit	d	Compressor wheel
110	Exhaust manifold	e	Control line
137	Turbocharger	f	Air admission
138	Charge air pipe	i	Turbine wheel
S66	Pressure switch, engine overload protection	A	Compressor inlet (fresh air)
Y30	Switch-over valve, engine overload protection	B	Compressor outlet (precompressed air)
		C	Exhaust gases to turbine wheel
		D	Exhaust outlet

- 2-pin connector on switchover valve (Y30) detach and briefly energize with voltage. The switchover valve must audibly actuate; replace if necessary.
- 1-pin connector on pressure switch (S66) detach and test for continuity with ohmmeter. The pressure switch (S66) is open in the off position.
- Engine overload protection switch (S66) remove.
 Connect pressure switch to cable of nozzle tester KDJE-P 400.
 Connect ohmmeter to pin of pressure switch and to housing. Build up pressure of 1.1 ± 0.15 bar at nozzle tester; the pressure switch must not have any continuity. Replace pressure switch if necessary.

Special tools




Commercial tester

Digital multimeter	e.g.Sun, DMM 5
Valve tester	e.g. Bosch, KDJE-P 400 (Bosch Order Designation)
Optionally O-6 bar pressure gauge	e.g. Bosch No. 1687 231 000
Optionally nozzle tester EFEP 60H	e.g.Bosch No. 0684 200 700

09-400 Removal and installation of air cleaner

A. Standard version and Federal as of 1984



Suction line (98)	installation position.
Closing catch, 6 off (92)	open, close.
Air cleaner cover (90)	remove, reinstall.
Air cleaner filter element (91)	remove, reinstall.
Nut (95a)	remove, reinstall.
Washer (95b)	remove, reinstall.
Bolt (95c)	remove, reinstall.
Bracket, 2 off (95)	remove, reinstall.
Air guide housing (94)	remove, reinstall.
Sealing boot (93)	remove, reinstall, ensure proper seating.
Rubber, 4 off (96)	replace according to condition.
Intake scoop (102)	remove, reinstall.
Pin (102a)	replace according to condition.


Engine 602.91

Air cleaner cover (90) and filter element (91) of revised material.

Production breakpoint:December 1989

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
201.126	602.911	086698	016956

B. Model 201



Air cleaner element (91)	remove, install. Ensure correct position during installation.
Air cleaner cover (90)	remove, install.
Air guide housing (94)	remove, install.
Air guide housing (94 a)	remove, install.
Cup seal (142)	remove, install.
Hose strap (144)	slacken, tighten, remove, install.
Intake pipe air line (145)	remove, install.
Stopper (146)	renew according to condition.
Nut (95 a)	bolt on, unbolt.
Air flow sensor (B2/1)	remove, install.
Wire clip (92)	unclip, clip in place.
Air cleaner cover (90 a)	remove, install.
Washer (95 b)	remove, install.
Bolt (95 c)	remove, install.

Repair Instruction

When the engine is running, the fender cover (right) must be removed, otherwise the fresh air intake (arrow) is blocked.

