




INSTALLATION

1. INSTALL MAF METER

- (a) Install the O-ring to the MAF meter.
- (b) Install the MAF meter with the 2 screws.

2. INSTALL AIR CLEANER CASE

- (a) Install the air cleaner case with the 3 bolts.
- (b) Connect the MAF meter connector.
- (c) Connect the air cleaner hose.