




HATSAN

ARMS COMPANY

HATSAN AIR RIFLE MOD 125




Camo



MagicWood



No		MOD 125 CODE
1	FRONT SIGHT FIBER	45-113
2	FRONT SIGHT ELEVATOR POST	45-114
3	FRONT SIGHT	45-111-6
4	BARREL	45-108-2
5	ELEVATOR/KNOB	45-205
6	REAR SIGHT	45-201-1
7	REAR SIGHT ELEVATOR POST	45-213
8	AIR JOINT	45-302-0
9	PLUNGER SEAL	45-304
10	MAIN SPRING	45-328-4
11	PLUNGER SEAL	45-326-3
12	HAMMER	45-309-1
13	METAL SPRING FOLLOWER	45-312-2
14	SCOPE STOP	45-316-0
15	SCOPE STOP SCREW	45-317
16	SPRING FOLLOWER PLASTIC WASHER	45-310-1
17	SPRING FOLLOWER METAL WASHER	45-310-0
18	SPRING FOLLOWER HEAD	45-312-1
19	SAFETY SCREW	45-303
20	M6 NUT	45-311
21	WASHER	45-518
22	TRIGGER ASSEMBLY CONNECTION SCREW	45-319
23	SPRING FOLLOWER PIN	45-301-1
24	TRIGGER PIN	45-416-1
25	COCKING LEVER SAFETY SPRING	45-334
26	COCKIN LEVER SAFETY	45-332
27	RECEIVER	45-327-3
28	RECEIVER LOCKIN PIN	45-322
29	REAR SIGHT CONNECTION SCREW	45-211
30	MAIN SCREW	45-323-1
31	COCKING LEVER	45-107-4
32	BARREL LOCKIN PIN	45-104
33	MONO-BLOCK SIDE WASHER	45-105
34	TRIGGER ASSEMBLY	45-422
35	COCKING LEVER PIN	45-102-0
36	STOCK	45-523
37	ADDITIONAL BUTT PLATE	45-531
38	BUTT PLATE	45-532
39	BUTT PLATE SCREW	45-533
40	SIDE SCREW	45-515-1
41	SAFETY TAIL	45-402
42	SAFETY	45-403
43	SAFETY LEVER SPRING	45-420
44	LOCKING PIN SPRING	45-106
45	TRIGGER GUARD SCREW	45-517
46	TRIGGER GUARD FRONT SCREW	45-516
47	TRIGGER GUARD	45-423-1



No		CODE
34A	Safety Rivet	45-00-406
34B	Safety Plate	45-00-403
34C	Safety Button	45-00-402
34D	White Sear	45-00-404
34E	Safety Spring	45-00-405
34F	Sear # 1	45-00-409
34G	Sear # 2	45-00-410
34H	Sear # 3	45-00-411
34I	Trigger Plate	45-00-408
34J	Sear Spring	45-00-418
34K	Trigger Spring	45-00-419
34L	Adjusting Screw	45-00-421
34M	Trigger	45-00-430
34N	Trigger Bushing Rivet	45-00-413
34O	Trigger Bushing	45-00-412
34P	Pin # 4	45-00-415
34R	Pin # 3	45-00-414
34S	Pin # 5	45-00-416