

Mr./Mrs/Ms: \_\_\_\_\_ Model: \_\_\_\_\_ Reg.No: \_\_\_\_\_

Invoice/Job no: \_\_\_\_\_ Odometer reading: \_\_\_\_\_ V.I.N: \_\_\_\_\_

|                 |       |       |       |       |        |        |        |        |         |         |
|-----------------|-------|-------|-------|-------|--------|--------|--------|--------|---------|---------|
| Service type:   | A     | B     | A     | B     | A      | B      | A      | B      | A       | B       |
| Months/,000 km: | 12/20 | 24/40 | 36/60 | 48/80 | 60/100 | 72/120 | 84/140 | 96/160 | 108/180 | 120/200 |

**Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked \***

**Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.**



## DISCOVERY SERIES II

(ALL MODELS FROM 02MY ON)

### MAINTENANCE CHECK SHEET

#### A B VEHICLE INTERIOR

1. ☐ ☐ Check condition and security of seats and seat belts
2. ☐ ☐ Check operation of all lamps, horns and warning indicators
3. ☐ ☐ Check operation of front/rear wipers and washers and condition of wiper blades
4. ☐ ☐ Check operation of handbrake
5. ☐ ☐ Replace alarm handset batteries

#### VEHICLE EXTERIOR

6. ☐ ☐ Annual corrosion/cosmetic inspection - **Only on vehicles sold after 21/11/98**
7. ☐ ☐ Remove road wheels
8. ☐ ☐ Check tyre pressures, condition and tread depth.  
LHF ☐ RHF ☐ RHR ☐ LHR ☐ Spare ☐
9. ☐ ☐ Inspect brake pads for wear, calipers for leaks and discs for condition
10. ☐ ☐ Inspect road wheel speed sensor harness for damage
11. ☐ ☐ Replace Brake Fluid ( Every 2 years )
12. ☐ ☐ Renew fuel filter element (**Diesel**)
13. ☐ ☐ Drain fuel sedimenter (**Diesel only**)
14. ☐ ☐ Refit road wheels to original hub position ( Use anti-sieze compound on spigot bore )
15. ☐ ☐ Visually check intercooler/radiator for external obstructions and fan blades for damage
16. ☐ ☐ Check ambient air sensor for damage
17. ☐ ☐ Check operation and Lubricate door locks, hinges, door checks, bonnet catch & fuel flap
18. ☐ ☐ Check condition of air suspension intake filter - **See recommendations**

#### UNDER BONNET

19. ☐ ☐ Renew anti-freeze
20. ☐ ☐ Check cooling, intercooler and heating systems for leaks, hoses and oil pipes for security and condition. Top up as required
21. ☐ ☐ Renew spark plugs
22. ☐ ☐ Renew air cleaner element and clean drain hole ( V8 )
23. ☐ ☐ Renew air cleaner element and clean dump valve ( Diesel )
24. ☐ ☐ Check condition of ancillary driving belt
25. ☐ ☐ Renew ancillary driving belt (V8)
26. ☐ ☐ Renew ancillary driving belt (Diesel)
27. ☐ ☐ Check/top up brake, PAS, clutch and ACE fluid levels and screen washer reservoirs
28. ☐ ☐ Check/adjust steering box
29. ☐ ☐ Check battery condition
30. ☐ ☐ Flush diesel intercooler element
31. ☐ ☐ Renew engine oil
32. ☐ ☐ Renew centrifuge rotor - **Diesel**
33. ☐ ☐ Renew full flow filter - **Diesel**

#### A B MAIN SERVICE (UNDER VEHICLE)

34. ☐ ☐ Renew engine oil filter **V8**
35. ☐ ☐ Renew manual gearbox oil
36. ☐ ☐ Check and top up manual gearbox oil
37. ☐ ☐ Renew automatic transmission filter - **First 40,000 km only**
38. ☐ ☐ Renew automatic transmission oil
39. ☐ ☐ Renew transfer box oil
40. ☐ ☐ Check and top up transfer box oil
41. ☐ ☐ Renew front and rear axle oil
42. ☐ ☐ Check and top up front and rear axle oil
43. ☐ ☐ Lubricate propeller shaft universal/sliding joints
44. ☐ ☐ Check for free play in anti-roll bar links and condition of rubber boots
45. ☐ ☐ Check condition of gaiters to ACE actuators
46. ☐ ☐ Replace ACE filter in valve block and replace lost fluid
47. ☐ ☐ Check visually, brake servo hose, brake, fuel, clutch pipes, unions, ACE pipes and electrical harnesses for chafing, leaks and corrosion.
48. ☐ ☐ Check for fluid leaks from power steering and suspension systems hydraulic pipes and unions for chafing and corrosion
49. ☐ ☐ Check for fluid leaks from Engine, Gearbox, Transfer box and Axles
50. ☐ ☐ Check exhaust system for leaks, security and damage
51. ☐ ☐ Check/tighten steering box and front and rear axles suspension fixings.
52. ☐ ☐ Check steering rod ball joint fixings and condition of ball joints and dust covers
53. ☐ ☐ Check shock absorbers/height sensors and harness assembly for leakage and damage
54. ☐ ☐ Check/tighten front and rear axle suspension link fixings, check condition of mounting rubbers
55. ☐ ☐ Check security of towing bracket
56. ☐ ☐ Check security of engine and transmission mounting rubbers - **V8 only**
57. ☐ ☐ If fault lamp(s) are illuminated, interrogate that system using TestBook and report findings.
58. ☐ ☐ Carry out road or roller test (see WARNING over page)
59. ☐ ☐ Endorse service record
60. ☐ ☐ Report any unusual features of vehicle condition and additional work required

The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road driving or frequent towing of trailers.

Service check completed and service portfolio book endorsed

Name: \_\_\_\_\_ Signature: \_\_\_\_\_ Date: \_\_\_\_\_