

Mr./Mrs/Ms: _____ Model: _____ Reg.No: _____

Invoice/Job no: _____ Odometer reading: _____ V.I.N: _____

Service type:	FS	A	B	A	B	A	B	A	B		
Months/,000 km:	3/5	12/20	24/40	36/60	48/80	60/100	72/120	84/140	96/160		

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.



DISCOVERY SERIES II

(ALL MODELS 99 MY TO 01 MY)

MAINTENANCE CHECK SHEET

FS A B VEHICLE INTERIOR

1. ☐ ☐ ☐ Check condition and security of seats and seat belts
2. ☐ ☐ ☐ Check operation of all lamps, horns and warning indicators
3. ☐ ☐ ☐ Check operation of front/rear wipers and washers and condition of wiper blades
4. ☐ ☐ ☐ Check operation of handbrake
5. ☐ ☐ ☐ Replace alarm handset batteries

VEHICLE EXTERIOR

6. ☐ ☐ ☐ Annual corrosion/cosmetic inspection - **Only on vehicles sold after 21/11/98**
7. ☐ ☐ ☐ Remove road wheels
8. ☐ ☐ ☐ Check tyre pressures, condition and tread depth.
LHF ☐ RHf ☐ RHR ☐ LHR ☐ Spare ☐
9. ☐ ☐ ☐ Inspect brake pads for wear , calipers for leaks and discs for condition
10. ☐ ☐ ☐ Inspect road wheel speed sensor harness for damage
11. ☐ ☐ ☐ Replace Brake Fluid (Every 2 years)
12. ☐ ☐ ☐ Renew fuel filter element (**Diesel**)
13. ☐ ☐ ☐ Drain fuel sedimenter (**Diesel only**)
14. ☐ ☐ ☐ Refit road wheels to original hub position (Use anti-sieze compound on spigot bore)
15. ☐ ☐ ☐ Visually check intercooler/radiator for external obstructions and fan blades for damage
16. ☐ ☐ ☐ Check ambient air sensor for damage
17. ☐ ☐ ☐ Check operation and Lubricate door locks, hinges, door checks, bonnet catch & fuel flap
18. ☐ ☐ ☐ Check condition of air suspension intake filter - **See recommendations**

UNDER BONNET

19. ☐ ☐ ☐ Renew anti-freeze
20. ☐ ☐ ☐ Check cooling, intercooler and heating systems for leaks , hoses and oil pipes for security and condition . Top up as required
21. ☐ ☐ ☐ Renew spark plugs
22. ☐ ☐ ☐ Renew air cleaner element and clean drain hole (V8)
23. ☐ ☐ ☐ Renew air cleaner element and clean dump valve (Diesel)
24. ☐ ☐ ☐ Check condition of ancillary driving belt
25. ☐ ☐ ☐ Renew ancillary driving belt (V8)
26. ☐ ☐ ☐ Renew ancillary driving belt (Diesel)
27. ☐ ☐ ☐ Check/top up brake, PAS, clutch and ACE fluid levels and screen washer reservoirs
28. ☐ ☐ ☐ Check/adjust steering box
29. ☐ ☐ ☐ Check battery condition
30. ☐ ☐ ☐ Flush diesel intercooler element
31. ☐ ☐ ☐ Renew engine oil
32. ☐ ☐ ☐ Renew centrifuge rotor - **Diesel**
33. ☐ ☐ ☐ Renew full flow filter - **Diesel**

FS A B MAIN SERVICE (UNDER VEHICLE)

34. ☐ ☐ ☐ Renew engine oil filter - **V8**
35. ☐ ☐ ☐ Renew manual gearbox oil
36. ☐ ☐ ☐ Check and top up manual gearbox oil
37. ☐ ☐ ☐ Renew automatic transmission filter - **First 40,000 km only**
38. ☐ ☐ ☐ Renew automatic transmission oil
39. ☐ ☐ ☐ Renew transfer box oil
40. ☐ ☐ ☐ Check and top up transfer box oil
41. ☐ ☐ ☐ Renew front and rear axle oil
42. ☐ ☐ ☐ Check and top up front and rear axle oil
43. ☐ ☐ ☐ Lubricate propeller shaft universal/sliding joints
44. ☐ ☐ ☐ Check for free play in anti-roll bar links and condition of rubber boots
45. ☐ ☐ ☐ Check condition of gaiters to ACE actuators
46. ☐ ☐ ☐ Replace ACE filter in valve block and replace lost fluid
47. ☐ ☐ ☐ Check visually, brake servo hose, brake, fuel, clutch pipes, unions, ACE pipes and electrical harnesses for chafing, leaks and corrosion.
48. ☐ ☐ ☐ Check for fluid leaks from power steering and suspension systems hydraulic pipes and unions for chafing and corrosion
49. ☐ ☐ ☐ Check for fluid leaks from Engine, Gearbox, Transfer box and Axles
50. ☐ ☐ ☐ Check exhaust system for leaks , security and damage
51. ☐ ☐ ☐ Check/tighten steering box and front and rear axles suspension fixings.
52. ☐ ☐ ☐ Check steering rod ball joint fixings and condition of ball joints and dust covers
53. ☐ ☐ ☐ Check shock absorbers/height sensors and harness assembly for leakage and damage
54. ☐ ☐ ☐ Check/tighten front and rear axle suspension link fixings, check condition of mounting rubbers
55. ☐ ☐ ☐ Check security of towing bracket
56. ☐ ☐ ☐ Check security of engine and transmission mounting rubbers - **V8 only**
57. ☐ ☐ ☐ If fault lamp(s) are illuminated, interrogate that system using TestBook and report findings.
58. ☐ ☐ ☐ Carry out road or roller test (see WARNING over page)
59. ☐ ☐ ☐ Endorse service record
60. ☐ ☐ ☐ Report any unusual features of vehicle condition and additional work required

The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road driving or frequent towing of trailers.

Service check completed and service portfolio book endorsed

Name: _____ Signature: _____ Date: _____

WARNING :

Two wheel roller tests must not be carried out . Four wheel roller tests must be restricted to 5km/hour.

IMPORTANT**OIL CHANGE DIESEL ENGINES**

If the vehicle is operated on fuel with a high sulphur content (over 1%) the oil change intervals must not exceed 10,000 km

VEHICLES FITTED WITH SUPPLEMENTARY RESTRAINT SYSTEMS

The seatbelt pre-tensioners (where fitted) and air bags must be replaced every TEN YEARS

Side air bags must be replaced every FIFTEEN YEARS

IT IS RECOMMENDED THAT :

At 120,000 Km or every six years, whichever is the sooner, all hydraulic brake fluid seal and hoses should be renewed.

All working surfaces of the caliper cylinders should be examined and renewed where necessary.

Vehicles used extensively in arduous/off road conditions - check the road wheel speed sensors, brake pads and calipers for abrasive wear at 1500 km (1000 miles) intervals

Air suspension vehicles used extensively in arduous/off road conditions will require the compressor inlet filter to be replaced at more regular intervals .

The Power Steering/ACE fluid reservoir should be replaced at 250,000Km

When the vehicle is used in dusty or field conditions or deep wading , frequent attention to the air cleaner may be required .

When the vehicle is used in areas where fuel quality is poor, more frequent draining of the fuel filter/sedimentor may be required.

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

GLOSSARY

FIRST SERVICE (FS)= The first service required after sale of vehicle.

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 20,000 km intervals, whichever occurs first.

Main Service "A"is applicable at 12 months/20,000 km, 36 months/60,000 km, 60 months/100,000 km 84 months/140,000 km and so on.

Main Service "B"is applicable at 24 months/40,000 km, 48 months/80,000 km, 72 months/120,000 km, 96 months/160,000 km and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 100k (This indicates that this item is only applicable every 60 months/ 100,000 km)